

V. A. Dobrev, R. D. Falgout, Tz. V. Kolev, N. A. Petersson, J. B. Schroder, U. M. Yang Center for Applied Scientific Computing (CASC) Lawrence Livermore National Laboratory Copyright (c) 2013, Lawrence Livermore National Security, LLC. Produced at the Lawrence Livermore National Laboratory. Written by the XBraid team. LLNL-CODE-660355. All rights reserved.

This file is part of XBraid. Please see the COPYRIGHT and LICENSE file for the copyright notice, disclaimer, and the GNU Lesser General Public License. Email xbraid-support@llnl.gov for support.

XBraid is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License (as published by the Free Software Foundation) version 2.1 dated February 1999.

XBraid is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the IMPLIED WARRANTY OF MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the terms and conditions of the GNU General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111- 1307 USA

Contents

1	Abst	tract		1
2	Intro	duction	1	2
	2.1	Meanir	ng of the name	2
	2.2	Overvi	ew of the XBraid Algorithm	2
		2.2.1	Two-Grid Algorithm	6
		2.2.2	Summary	6
	2.3	Overvi	ew of the XBraid Code	7
		2.3.1	Parallel decomposition and memory	7
		2.3.2	Cycling and relaxation strategies	8
		2.3.3	Overlapping communication and computation	9
		2.3.4	Configuring the XBraid Hierarchy	9
		2.3.5	Halting tolerance	10
		2.3.6	Heat equation example	11
	2.4	Citing	XBraid	12
	2.5	Summ	ary	12
3	Exar	mnla		12
3	Exai	lible		12
4	Build	ding XB	Braid	18
5	Com	piling a	and running the examples	18
6	Codi	ing Styl	le e	19
7	Usin	g Doxy	gen	19
8	Regi	ression	Testing	20
9	Mod	ule Inde		24
9	9.1		es	24
	3.1	Module		24
10	Data	Struct	ure Index	25
	10.1	Data S	Structures	25
11	File	Index		25
	11.1	File Lis	st	25
12	Mod	ule Dod	cumentation	25
	12.1	User-w	vritten routines	25

iv CONTENTS

		12.1.1	Detailed Description	26
		12.1.2	Typedef Documentation	26
	12.2	User in	terface routines	29
		12.2.1	Detailed Description	29
	12.3	Genera	Il Interface routines	30
		12.3.1	Detailed Description	30
		12.3.2	Typedef Documentation	30
		12.3.3	Function Documentation	31
	12.4	XBraid	status routines	38
		12.4.1	Detailed Description	39
		12.4.2	Macro Definition Documentation	39
		12.4.3	Typedef Documentation	39
		12.4.4	Function Documentation	39
	12.5	XBraid	test routines	46
		12.5.1	Detailed Description	46
		12.5.2	Function Documentation	46
10	Data	C4	The Design and Atlanta	- 4
13			Assess Obstacle Obstacle Defended	51
	13.1		AccessStatus Struct Reference	51
			Detailed Description	51
	40.0		Field Documentation	51
	13.2		AccuracyHandle Struct Reference	51
			Detailed Description	52
	40.0		Field Documentation	52
	13.3		CoarsenRefStatus Struct Reference	52
			Detailed Description	53
	40.4		Field Documentation	53
	13.4		CommHandle Struct Reference	53
			Detailed Description	53
	40.5		Field Documentation	53
	13.5		Core Struct Reference	54
			Detailed Description	55
			Field Documentation	55
	13.6		Grid Struct Reference	58
			Detailed Description	59
			Field Documentation	59
	13.7	braid	PhiStatus Struct Reference	61

1 Abstract 1

		13.7.1	Detailed Description	61
		13.7.2	Field Documentation	61
14	File I	Docume	entation	6
	14.1	_braid.	h File Reference	61
		14.1.1	Detailed Description	62
		14.1.2	Macro Definition Documentation	63
		14.1.3	Function Documentation	63
		14.1.4	Variable Documentation	66
	14.2	braid.h	File Reference	66
		14.2.1	Detailed Description	67
	14.3	braid_c	defs.h File Reference	68
		14.3.1	Detailed Description	68
		14.3.2	Macro Definition Documentation	68
		14.3.3	Typedef Documentation	68
		14.3.4	Variable Documentation	69
	14.4	braid_s	status.h File Reference	69
		14.4.1	Detailed Description	70
	14.5	braid_t	est.h File Reference	70
		14.5.1	Detailed Description	7(
	14.6	util.h Fi	ile Reference	70
		14.6.1	Detailed Description	7-
				7-

1 Abstract

Index

This package implements an optimal-scaling multigrid solver for the (non)linear systems that arise from the discretization of problems with evolutionary behavior. Typically, solution algorithms for evolution equations are based on a time-marching approach, solving sequentially for one time step after the other. Parallelism in these traditional time-integration techniques is limited to spatial parallelism. However, current trends in computer architectures are leading towards systems with more, but not faster, processors, i.e., clock speeds are stagnate. Therefore, faster overall runtimes must come from greater parallelism. One approach to achieve parallelism in time is with multigrid, but extending classical multigrid methods for elliptic operators to this setting is a significant achievement. In this software, we implement a non-intrusive, optimal-scaling time-parallel method based on multigrid reduction techniques. The examples in the package demonstrate optimality of our multigrid-reduction-in-time algorithm (MGRIT) for solving a variety of equations in two and three spatial dimensions. These examples can also be used to show that MGRIT can achieve significant speedup in comparison to sequential time marching on modern architectures.

72

It is **strongly recommended** that you also read Parallel Time Integration with Multigrid after reading the Overview of the XBraid Algorithm. It is a more in depth discussion of the algorithm and associated ex-

periments.

2 Introduction

2.1 Meaning of the name

We chose the package name XBraid to stand for *Time-Braid*, where X is the first letter in the Greek work for time, *Chronos*. The algorithm *braids* together time-grids of different granularity in order to create a multigrid method and achieve parallelism in the time dimension.

2.2 Overview of the XBraid Algorithm

The goal of XBraid is to solve a problem faster than a traditional time marching algorithm. Instead of sequential time marching, XBraid solves the problem iteratively by simultaneously updating a space-time solution guess over all time values. The initial solution guess can be anything, even a random function over space-time. The iterative updates to the solution guess are done by constructing a hierarchy of temporal grids, where the finest grid contains all of the time values for the simulation. Each subsequent grid is a coarser grid with fewer time values. The coarsest grid has a trivial number of time steps and can be quickly solved exactly. The effect is that solutions to the time marching problem on the coarser (i.e., cheaper) grids can be used to correct the original finest grid solution. Analogous to spatial multigrid, the coarse grid correction only *corrects* and *accelerates* convergence to the finest grid solution. The coarse grid does not need to represent an accurate time discretization in its own right. Thus, a problem with many time steps (thousands, tens of thousands or more) can be solved with 10 or 15 XBraid iterations, and the overall time to solution can be greatly sped up. However, this is achieved at the cost of more computational resources.

To understand how XBraid differs from traditional time marching, consider the simple linear advection equation, $u_t = -cu_x$. The next figure depicts how one would typically evolve a solution here with sequential time stepping. The initial condition is a wave, and this wave propagates sequentially across space as time increases.




Figure 1: Sequential time stepping.

XBraid instead begins with a solution guess over all of space-time, which for demonstration, we let be random. An XBraid iteration does

1. Relaxation on the fine grid, i.e., the grid that contains all of the desired time values Relaxation is just a local application of the time stepping scheme, e.g., backward Euler.

- 2. Restriction to the first coarse grid, i.e., interpolate the problem to a grid that contains fewer time values, say every second or every third time value.
- 3. Relaxation on the first coarse grid
- 4. Restriction to the second coarse grid and so on...
- 5. When a coarse grid of trivial size (say 2 time steps) is reached, it is solved exactly.
- 6. The solution is then interpolated from the coarsest grid to the finest grid

One XBraid iteration is called a *cycle* and these cycles continue until the solution is accurate enough. This is depicted in the next figure, where only a few iterations are required for this simple problem.




Figure 2: XBraid iterations.

There are a few important points to make.

- The coarse time grids allow for global propagation of information across space-time with only one XBraid iteration. This is visible in the above figure by observing how the solution is updated from iteration 0 to iteration 1.
- · Using coarser (cheaper) grids to correct the fine grid is analogous to spatial multigrid.
- Only a few XBraid iterations are required to find the solution over 1024 time steps. Therefore if enough processors are available to parallelize XBraid, we can see a speedup over traditional time stepping (more on this later).
- This is a simple example, with evenly space time steps. XBraid is structured to handle variable time step sizes and adaptive time step sizes, and these features will be coming.

To firm up our understanding, let's do a little math. Assume that you have a general system of ordinary differential equations (ODEs),

$$u'(t) = f(t, u(t)), \quad u(0) = u_0, \quad t \in [0, T].$$

Next, let $t_i = i\delta t, i = 0, 1, ..., N$ be a temporal mesh with spacing $\delta t = T/N$, and u_i be an approximation to $u(t_i)$. A general one-step time discretization is now given by

$$u_0 = g_0$$

 $u_i = \Phi_i(u_{i-1}) + g_i, \quad i = 1, 2, ..., N.$

Traditional time marching would first solve for i = 1, then solve for i = 2, and so on. For linear time propagators $\{\Phi_i\}$, this can also be expressed as applying a direct solver (a forward solve) to the following system:

$$A\mathbf{u} \equiv \begin{pmatrix} I & & & \\ -\Phi_1 & I & & \\ & \ddots & \ddots & \\ & & -\Phi_N & I \end{pmatrix} \begin{pmatrix} u_0 \\ u_1 \\ \vdots \\ u_N \end{pmatrix} = \begin{pmatrix} g_0 \\ g_1 \\ \vdots \\ g_N \end{pmatrix} \equiv \mathbf{g}$$

or

$$A\mathbf{u} = \mathbf{g}$$
.

This process is optimal and O(N), but it is sequential. XBraid achieves parallelism in time by replacing this sequential solve with an optimal multigrid reduction iterative method ¹ applied to only the time dimension. This approach is

- nonintrusive, in that it coarsens only in time and the user defines Φ. Thus, users can continue using existing time stepping codes by wrapping them into our framework.
- optimal and O(N), but O(N) with a higher constant than time stepping. Thus with enough computational resources, XBraid will outperform sequential time stepping.
- · highly parallel

We now describe the two-grid process in more detail, with the multilevel analogue being a recursive application of the process. We also assume that Φ is constant for notational simplicity. XBraid coarsens in the time dimension with factor m>1 to yield a coarse time grid with $N_{\Delta}=N/m$ points and time step $\Delta T=m\delta t$. The corresponding coarse grid problem,

$$A_{\Delta} = egin{pmatrix} I & & & & & \ -\Phi_{\Delta} & I & & & & \ & \ddots & \ddots & & \ & & -\Phi_{\Delta} & I \end{pmatrix},$$

is obtained by defining coarse grid propagators $\{\Phi_{\Delta}\}$ which are at least as cheap to apply as the fine scale propagators $\{\Phi\}$. The matrix A_{Δ} has fewer rows and columns than A, e.g., if we are coarsening in time by 2, A_{Δ} has one half as many rows and columns.

This coarse time grid induces a partition of the fine grid into C-points (associated with coarse grid points) and F-points, as visualized next. C-points exist on both the fine and coarse time grid, but F-points exist only on the fine time scale.

Every multigrid algorithm requires a relaxation method and an approach to transfer values between grids. Our relaxation scheme alternates between so-called F-relaxation and C-relaxation as illustrated next. F-relaxation updates the F-point values $\{u_j\}$ on interval (T_i, T_{i+1}) by simply propagating the C-point value u_{mi} across the interval using the time propagator $\{\Phi\}$. While this is a sequential process, each F-point interval update is independent from the others and can be computed in parallel. Similarly, C-relaxation updates the C-point value u_{mi} based on the F-point value u_{mi-1} and these updates can also be computed in parallel. This approach to relaxation can be thought of as line relaxation in space in that the residual is set to 0 for an entire time step.

The F updates are done simultaneously in parallel, as depicted next.




Figure 3: Update all F-point intervals in parallel, using the time propagator Φ .

Following the F sweep, the C updates are also done simultaneously in parallel, as depicted next.

¹ Ries, Manfred, Ulrich Trottenberg, and Gerd Winter. "A note on MGR methods." Linear Algebra and its Applications 49 (1983): 1-26.




Figure 4: Update all C-points in parallel, using the time propagator Φ .

In general, FCF- and F-relaxation will refer to the relaxation methods used in XBraid. We can say

- FCF- or F-relaxation is highly parallel.
- But, a sequential component exists equaling the number of F-points between two C-points.
- XBraid uses regular coarsening factors, i.e., the spacing of C-points happens every m points.

After relaxation, comes forming the coarse grid error correction. To move quantities to the coarse grid, we use the restriction operator *R* which simply injects values at C-points from the fine grid to the coarse grid,

$$R = \begin{pmatrix} I & & & \\ 0 & & & \\ \vdots & & & \\ 0 & & & \\ & I & & \\ & 0 & & \\ & \vdots & & \\ & 0 & & \\ & & \ddots \end{pmatrix}^{T}$$

The spacing between each I is m-1 block rows. While injection is simple, XBraid always does an F-relaxation sweep before the application of R, which is equivalent to using the transpose of harmonic interpolation for restriction (see Parallel Time Integration with Multigrid).

To define the coarse grid equations, we apply the Full Approximation Scheme (FAS) method, which is a nonlinear version of multigrid. This is to accommodate the general case where f is a nonlinear function. In FAS, the solution guess and residual (i.e., $\mathbf{u}, \mathbf{g} - A\mathbf{u}$) are restricted. This is in contrast to linear multigrid which typically restricts only the residual equation to the coarse grid. This algorithmic change allows for the solution of general nonlinear problems. For more details, see PDF by Van Henson for a good introduction to FAS. However, FAS was originally invented by Achi Brandt.

A central question in applying FAS is how to form the coarse grid matrix A_{Δ} , which in turn asks how to define the coarse grid time stepper Φ_{Δ} . One of the simplest choices (and one frequently used in practice) is to let Φ_{Δ} simply be Φ but with the coarse time step size $\Delta T = m \delta t$. For example, if $\Phi = (I - \delta t A)^{-1}$ for some backward Euler scheme, then $\Phi_{\Delta} = (I - m \delta t A)^{-1}$ would be one choice.

With a Φ_{Δ} defined, the coarse grid equation

$$A_{\Delta}(\mathbf{v}_{\Delta}) = A_{\Delta}(\mathbf{u}_{\Delta}) + \mathbf{r}_{\Delta}$$

is then solved. Finally, FAS defines a coarse grid error approximation $\mathbf{e}_{\Delta} = \mathbf{v}_{\Delta} - \mathbf{u}_{\Delta}$, which is interpolated with P_{Φ} back to the fine grid and added to the current solution guess. Interpolation is equivalent to injecting the coarse grid to the C-points on the fine grid, followed by an F-relaxation sweep (i.e., it is equivalent to harmonic interpolation, as mentioned

above about restriction). That is,

where m is the coarsening factor. See Two-Grid Algorithm for a concise description of the FAS algorithm for MGRIT.

2.2.1 Two-Grid Algorithm

The two-grid FAS process is captured with this algorithm. Using a recursive coarse grid solve (i.e., step 3 becomes a recursive call) makes the process multilevel. Halting is done based on a residual tolerance. If the operator is linear, this FAS cycle is equivalent to standard linear multigrid. Note that we represent A as a function below, whereas the above notation was simplified for the linear case.

- 1. Relax on $A(\mathbf{u}) = \mathbf{g}$ using FCF-relaxation
- 2. Restrict the fine grid approximation and its residual:

$$\mathbf{u}_{\Delta} \leftarrow R\mathbf{u}, \quad \mathbf{r}_{\Delta} \leftarrow R(\mathbf{g} - A(\mathbf{u}),$$

which is equivalent to updating each individual time step according to

$$u_{\Delta,i} \leftarrow u_{mi}, \quad r_{\Delta,i} \leftarrow g_{mi} - A(\mathbf{u})_{mi} \quad \text{for} \quad i = 0, ..., N_{\Delta}.$$

- 3. Solve $A_{\Delta}(\mathbf{v}_{\Delta}) = A_{\Delta}(\mathbf{u}_{\Delta}) + \mathbf{r}_{\Delta}$
- 4. Compute the coarse grid error approximation: ${f e}_\Delta = {f v}_\Delta {f u}_\Delta$
- 5. Correct: $\mathbf{u} \leftarrow \mathbf{u} + P\mathbf{e}_{\Delta}$

This is equivalent to updating each individual time step by adding the error to the values of **u** at the C-points:

$$u_{mi} = u_{mi} + e_{\Delta,i}$$
,

followed by an F-relaxation sweep applied to u.

2.2.2 Summary

In summary, a few points are

- XBraid is an iterative solver for the global space-time problem.
- ullet The user defines the time stepping routine Φ and can wrap existing code to accomplish this.
- XBraid convergence will depend heavily on how well Φ_{Δ} approximates Φ^m , that is how well a time step size of $m\delta t = \Delta T$ will approximate m applications of the same time integrator for a time step size of δt . This is a subject of research, but this approximation need not capture fine scale behavior, which is instead captured by relaxation on the fine grid.

- The coarsest grid is solved exactly, i.e., sequentially, which can be a bottleneck for two-level methods like Parareal, ² but not for a multilevel scheme like XBraid where the coarsest grid is of trivial size.
- By forming the coarse grid to have the same sparsity structure and time stepper as the fine grid, the algorithm can recur easily and efficiently.
- · Interpolation is ideal or exact, in that an application of interpolation leaves a zero residual at all F-points.
- The process is applied recursively until a trivially sized temporal grid is reached, e.g., 2 or 3 time points. Thus, the coarsening rate m determines how many levels there are in the hierarchy. For instance in this figure, a 3 level hierarchy is shown. Three levels are chosen because there are six time points, m=2 and $m^2 < 6 \le m^3$. If the coarsening rate had been m=4 then there would only be two levels because, there would be no more points to coarsen!



By default, XBraid will subdivide the time domain into evenly sized time steps. XBraid is structured to handle variable time step sizes and adaptive time step sizes, and these features are coming.

2.3 Overview of the XBraid Code

XBraid is designed to run in conjunction with an existing application code that can be wrapped per our interface. This application code will implement some time marching simulation like fluid flow. Essentially, the user has to take their application code and extract a stand-alone time-stepping function Φ that can evolve a solution from one time value to another, regardless of time step size. After this is done, the XBraid code takes care of the parallelism in the time dimension.


XBraid

- is written in C and can easily interface with Fortran and C++
- · uses MPI for parallelism
- self documents through comments in the source code and through $\ast.md$ files
- · functions and structures are prefixed by braid
 - User routines are prefixed by braid_
 - Developer routines are prefixed by _braid_

2.3.1 Parallel decomposition and memory

- XBraid decomposes the problem in parallel as depicted next. As you can see, traditional time stepping only stores
 one time step at a time, but only enjoys a spatial data decomposition and spatial parallelism. On the other hand,
 XBraid stores multiple time steps simultaneously and each processor holds a space-time chunk reflecting both
 the spatial and temporal parallelism.
- XBraid only handles temporal parallelism and is agnostic to the spatial decomposition. See braid_Split-Commworld. Each processor owns a certain number of CF intervals of points. In the following figure, processor 1 and processor 2 each own 2 CF intervals. XBraid distributes intervals evenly on the finest grid.

² Lions, J., Yvon Maday, and Gabriel Turinici. "A"parareal"in time discretization of PDE's." Comptes Rendus de l'Academie des Sciences Series I Mathematics 332.7 (2001): 661-668.



- XBraid increases the parallelism significantly, but now several time steps need to be stored, requiring more memory. XBraid employs two strategies to address the increased memory costs.
 - First, one need not solve the whole problem at once. Storing only one space-time slab is advisable. That
 is, solve for as many time steps (say k time steps) as you have available memory for. Then move on to the
 next k time steps.
 - Second, XBraid only stores the C-points. Whenever an F-point is needed, it is generated by F-relaxation. More precisely, we only store the red C-point time values in the previous figure. Coarsening is usually aggressive with m=8,16,32,..., so the storage requirements of XBraid are significantly reduced when compared to storing all of the time values.

2.3.2 Cycling and relaxation strategies


There are two main cycling strategies available in XBraid, F-and V-cycles. These two cycles differ in how often and the order in which coarse levels are visited. A V-cycle is depicted next, and is a simple recursive application of the Two-Grid Algorithm.



An F-cycle visits coarse grids more frequently and in a different order. Essentially, an F-cycle uses a V-cycle as the post-smoother, which is an expensive choice for relaxation. But, this extra work gives you a closer approximation to a two-grid cycle, and a faster convergence rate at the extra expense of more work. The effectiveness of a V-cycle as a relaxation scheme can be seen in Figure 2, where one V-cycle globally propagates and *smoothes* the error. The cycling strategy of an F-cycle is depicted next.

Next, we make a few points about F- versus V-cycles.

One V-cycle iteration is cheaper than one F-cycle iteration.



But, F-cycles often converge more quickly. For some test cases, this difference can be quite large. The cycle
choice for the best time to solution will be problem dependent. See Heat equation example for a case study of
cycling strategies.


The number of FC relaxation sweeps is another important algorithmic setting. Note that at least one F-relaxation sweep is always done on a level. A few summary points about relaxation are as follows.

- Using FCF (or even FCFCF, FCFCFCF) relaxation, corresponding to passing *braid_SetNRelax* a value of 1, 2 or 3 respectively, will result in an XBraid cycle that converges more quickly as the number of relaxations grows.
- But as the number of relaxations grows, each XBraid cycle becomes more expensive. The optimal relaxation strategy for the best time to solution will be problem dependent.
- However, a good first step is to try FCF on all levels (i.e., braid_SetNRelax(core, -1, 1)).
- A common optimization is to first set FCF on all levels (i.e., braid_setnrelax(core, -1, 1)), but then overwrite the FCF option on level 0 so that only F-relaxation is done on level 0, (i.e., braid_setnrelax(core, 0, 1)). This strategy can work well with F-cycles.
- See Heat equation example for a case study of relaxation strategies.

Last, Parallel Time Integration with Multigrid has a more in depth case study of cycling and relaxation strategies

2.3.3 Overlapping communication and computation

XBraid effectively overlaps communication and computation. The main computational kernel of XBraid is one relaxation sweep touching all the CF intervals. At the start of a relaxation sweep, each process first posts a non-blocking receive at its left-most point. It then carries out F-relaxation in each interval, starting with the right-most interval to send the data to the neighboring process as soon as possible. If each process has multiple CF intervals at this XBraid level, the strategy allows for complete overlap.



2.3.4 Configuring the XBraid Hierarchy

Some of the more basic XBraid function calls allow you to control aspects discussed here.

- braid_SetFMG: switches between using F- and V-cycles.
- braid_SetMaxIter: sets the maximum number of XBraid iterations
- braid SetCFactor: sets the coarsening factor for any (or all levels)
- braid_SetNRelax: sets the number of CF-relaxation sweeps for any (or all levels)
- · braid SetRelTol, braid SetAbsTol: sets the stopping tolerance
- braid_SetMinCoarse: sets the minimum possible coarse grid size

braid SetMaxLevels: sets the maximum number of levels in the XBraid hierarchy

2.3.5 Halting tolerance

Another important configuration aspect regards setting a residual halting tolerance. Setting a tolerance involves these three XBraid options:

1. braid PtFcnSpatialNorm

This user-defined function carries out a spatial norm by taking the norm of a braid_Vector. A common choice is the standard Eucliden norm (2-norm), but many other choices are possible, such as an L2-norm based on a finite element space.

2. braid SetTemporalNorm

This option determines how to obtain a global space-time residual norm. That is, this decides how to combine the spatial norms returned by braid_PtFcnSpatialNorm at each time step to obtain a global norm over space and time. It is this global norm that then controls halting.

There are three options for setting the *tnorm* value passed to braid_SetTemporalNorm. We let the summation index i be over all C-point values on the fine time grid, k refer to the current XBraid iteration, r be residual values, $space_time$ norms be a norm over the entire space-time domain and $spatial_norm$ be the user-defined spatial norm from braid_PtFcnSpatialNorm. Thus, r_i is the residual at the ith C-point, and $r^{(k)}$ is the residual at the kth XBraid iteration. The three options are then defined as,

tnorm=1: One-norm summation of spatial norms

$$\|r^{(k)}\|_{ extsf{space_time}} = \Sigma_i \|r_i^{(k)}\|_{ extsf{spatial_norm}}$$

If braid_PtFcnSpatialNorm is the one-norm over space, then this is equivalent to the one-norm of the global space-time residual vector.

• tnorm=2: Two-norm summation of spatial norms

$$||r^{(k)}||_{\text{space_time}} = \left(\sum_{i} ||r_i^{(k)}||_{\text{spatial_norm}}^2\right)^{1/2}$$

If braid_PtFcnSpatialNorm is the Euclidean norm (two-norm) over space, then this is equivalent to the Euclidean-norm of the global space-time residual vector.

tnorm=3: Infinity-norm combination of spatial norms

$$\|r^{(k)}\|_{\texttt{space_time}} = \max_{i} \|r_{i}^{(k)}\|_{\texttt{spatial_norm}}$$

If braid_PtFcnSpatialNorm is the infinity-norm over space, then this is equivalent to the infinity-norm of the global space-time residual vector.

The default choice is tnorm=2

- 3. braid SetAbsTol, braid SetRelTol
 - · If an absolute tolerance is used, then

$$||r^{(k)}||_{\text{space time}} < \text{tol}$$

defines when to halt.

· If a relative tolerance is used, then

$$\frac{\|r^{(k)}\|_{\texttt{space_time}}}{\|r^{(0)}\|_{\texttt{space_time}}} < \mathsf{tol}$$

defines when to halt. That is, the current *kth* residual is scaled by the initial residual before comparison to the halting tolerance. This is similar to typical relative residual halting tolerances used in spatial multigrid, but can be a dangerous choice in this setting.

Care should be practiced when choosing a halting tolerance. For instance, if a relative tolerance is used, then issues can arise when the initial guess is zero for large numbers of time steps. Taking the case where the initial guess (defined by $\frac{\text{braid}}{\text{ptFcnInit}}$) is 0 for all time values t > 0, the initial residual norm will essentially only be nonzero at the first time value,


$$\|r^{(0)}\|_{\texttt{space_time}} \approx \|r_1^{(k)}\|_{\texttt{spatial_norm}}$$

This will skew the relative halting tolerance, especially if the number of time steps increases, but the initial residual norm does not.

A better strategy is to choose an absolute tolerance that takes your space-time domain size into account, as in Section Heat equation example, or to use an infinity-norm temporal norm option.

2.3.6 Heat equation example

Here is some experimental data for the 2D heat equation, $u_t = u_{xx} + u_{yy}$ generated by examples/drive-02. The problem



setup is as follows.

- · Backwards Euler is used as the time stepper.
- We used a Linux cluster with 4 cores per node, a Sandybridge Intel chipset, and a fast Infiniband interconnect.
- The space-time problem size was $129^2 \times 16,192$ over the unit cube $[0,1] \times [0,1] \times [0,1]$.
- The coarsening factor was m = 16 on the finest level and m = 2 on coarser levels.
- Since 16 processors optimized the serial time stepping approach, 16 processors in space are also used for the XBraid experiments. So for instance 512 processrs in the plot corresponds to 16 processors in space and 32 processors in time, 16*32=512. Thus, each processor owns a space-time hypercube of $(129^2/16) \times (16,192/32)$. See Parallel decomposition and memory for a depiction of how XBraid breaks the problem up.
- Various relaxation and V and F cycling strategies are experimented with.
 - V-cycle, FCF denotes V-cycles and FCF-relaxation on each level.
 - V-cycle, F-FCF denotes V-cycles and F-relaxation on the finest level and FCF-relaxation on all coarser levels.
 - F-cycle, F denotes F-cycles and F-relaxation on each level.
- The initial guess at time values for t > 0 is zero, which is typical.
- The halting tolerance corresponds to a discrete L2-norm and was

$$tol = \frac{10^{-8}}{\sqrt{(h_x)^2 h_t}},$$

where h_x and h_t are the spatial and temporal grid spacings, respectively.

This corresponds to passing *tol* to braid_SetAbsTol, passing *2* to braid_SetTemporalNorm and defining braid_-PtFcnSpatialNorm to be the standard Euclidean 2-norm. All together, this appropriately scales the space-time residual in way that is relative to the number of space-time grid points (i.e., it approximates the L2-norm).

Regarding the performance, we can say

- The best speedup is 10x and this would grow if more processors were available.
- Although not shown, the iteration counts here are about 10-15 XBraid iterations. See Parallel Time Integration with Multigrid for the exact iteration counts.
- At smaller core counts, serial time stepping is faster. But at about 256 processors, there is a crossover and XBraid is faster.
- You can see the impact of the cycling and relaxation strategies discussed in Cycling and relaxation strategies.
 For instance, even though V-cycle, F-FCF is a weaker relaxation strategy than V-cycle, FCF (i.e., the XBraid convergence is slower), V-cycle, F-FCF has a faster time to solution than V-cycle, FCF because each cycle is cheaper.
- In general, one level of aggressive coarsening (here by a factor 16) followed by slower coarsening was found to be best on this machine.

Achieving the best speedup can require some tuning, and it is recommended to read Parallel Time Integration with Multigrid where this 2D heat equation example is explored in much more detail.

2.4 Citing XBraid

To cite XBraid, please state in your text the version number from the VERSION file, and please cite the project website in your bibliography as

[1] XBraid: Parallel multigrid in time. http://llnl.gov/casc/xbraid.

The corresponding BibTex entry is

```
@misc{xbraid-package,
  title = {{XB}raid: Parallel multigrid in time},
  howpublished = {\url{http://llnl.gov/casc/xbraid}}
}
```

2.5 Summary

- XBraid applies multigrid to the time dimension.
 - This exposes concurrency in the time dimension.
 - The potential for speedup is large, 10x, 100x, ...
- This is a non-intrusive approach, with an unchanged time discretization defined by user.
- Parallel time integration is only useful beyond some scale. This is evidenced by the experimental results below. For smaller numbers of cores sequential time stepping is faster, but at larger core counts XBraid is much faster.
- The more time steps that you can parallelize over, the better your speedup will be.
- XBraid is optimal for a variety of parabolic problems (see the examples directory).

3 Example

A Simple Example

3 Example 13

User Defined Structures and Wrappers

As mentioned, the user must wrap their existing time stepping routine per the XBraid interface. To do this, the user must define two data structures and some wrapper routines. To make the idea more concrete, we now give these function definitions from examples/drive-01, which implements a scalar ODE, $u_t = \lambda u$.

The two data structures are:

} my_App;

1. **App**: This holds a wide variety of information and is *global* in that it is passed to every function. This structure holds everything that the user will need to carry out a simulation. Here, this is just the global MPI communicator and few values describing the temporal domain.

```
typedef struct _braid_App_struct
{
    MPI_Comm comm;
    double tstart;
    double tstop;
    int ntime;
```

2. **Vector**: this defines (roughly) a state vector at a certain time value. It could also contain any other information related to this vector which is needed to evolve the vector to the next time value, like mesh information. Here, the vector is just a scalar double.

```
typedef struct _braid_Vector_struct
{
   double value;
} my_Vector;
```

The user must also define a few wrapper routines. Note, that the app structure is the first argument to every function.

1. **Phi**: This function tells XBraid how to take a time step, and is the core user routine. The user must advance the vector *u* from time *tstart* to time *tstop*. Note how the time values are given to the user through the *status* structure and associated Get routines. The *rfactor ptr* parameter is an advanced topic not used here.

Here advancing the solution just involves the scalar λ .

Importantly, the g_i function (from Overview of the XBraid Algorithm) must be incorporated into Phi, so that $\Phi(u_i) \to u_{i+1}$

```
int
my_Phi(braid_App
                       app,
       braid_Vector
                       u.
       braid_PhiStatus status)
   double tstart;
                               /* current time */
                              /* evolve to this time*/
   double tstop;
   braid_PhiStatusGetTstartTstop(status, &tstart, &tstop);
   /\star On the finest grid, each value is half the previous value \star/
   (u->value) = pow(0.5, tstop-tstart)*(u->value);
   /* Zero rhs for now */
   (u->value) += 0.0;
   /* no refinement */
   braid_PhiStatusSetRFactor(status, 1);
   return 0;
```

2. **Init**: This function tells XBraid how to initialize a vector at time *t*. Here that is just allocating and setting a scalar on the heap.

```
u = (my_Vector *) malloc(sizeof(my_Vector));
if (t == 0.0)
{
    /* Initial guess */
    (u->value) = 1.0;
}
else
{
    /* Random between 0 and 1 */
    (u->value) = ((double)rand()) / RAND_MAX;
}
*u_ptr = u;
return 0;
}
```

3. **Clone**: This function tells XBraid how to clone a vector into a new vector.

4. Free: This function tells XBraid how to free a vector.

5. **Sum**: This function tells XBraid how to sum two vectors (AXPY operation).

6. **SpatialNorm**: This function tells XBraid how to take the norm of a braid_Vector and is used for halting. This norm is only over space. A common norm choice is the standard Euclidean norm, but many other choices are possible, such as an L2-norm based on a finite element space. The norm choice should be based on what makes sense for you problem. How to accumulate spatial norm values to obtain a global space-time residual norm for halting decisions is controlled by braid_SetTemporalNorm.

3 Example 15

```
return 0;
```

7. **Access**: This function allows the user access to XBraid and the current solution vector at time *t*. This is most commonly used to print solution(s) to screen, file, etc... The user defines what is appropriate output. Notice how you are told the time value *t* of the vector *u* and even more information in *astatus*. This lets you tailor the output to only certain time values at certain XBraid iterations. Querying *astatus* for such information is done through *braid_AccessStatusGet**(..)* routines.

The frequency of the calls to *access* is controlled through braid_SetAccessLevel. For instance, if access_level is set to 2, then *access* is called every XBraid iteration and on every XBraid level. In this case, querying *astatus* to determine the current XBraid level and iteration will be useful. This scenario allows for even more detailed tracking of the simulation.

Eventually, this routine will allow for broader access to XBraid and computational steering.

See examples/drive-02 and examples/drive-04 for more advanced uses of the *access* function. Drive-04 uses *access* to write solution vectors to a GLVIS visualization port, and examples/drive-02 uses *access* to write to .vtu files.

```
int
my_Access(braid_App
                             app,
         braid_Vector
         braid_AccessStatus astatus)
   MPI_Comm comm = (app->comm);
   double
             tstart = (app->tstart);
             tstop = (app->tstop);
   double
   int
             ntime = (app->ntime);
   int
             index, myid;
   char
             filename[255];
   FILE
             *file;
   double
             t;
   braid_AccessStatusGetT(astatus, &t);
   index = ((t-tstart) / ((tstop-tstart)/ntime) + 0.1);
   MPI_Comm_rank(comm, &myid);
   sprintf(filename, "%s.%07d.%05d", "drive-01.out", index, myid);
   file = fopen(filename, "w");
   fprintf(file, "%.14e\n", (u->value));
   fflush (file):
   fclose(file);
   return 0;
```

8. **BufSize**, **BufPack**, **BufUnpack**: These three routines tell XBraid how to communicate vectors between processors. *BufPack* packs a vector into a void * buffer for MPI and then *BufUnPack* unpacks it from void * to vector. Here doing that for a scalar is trivial. *BufSize* computes the upper bound for the size of an arbitrary vector.


Note how *BufPack* also returns a size pointer. This size pointer should be the exact number of bytes packed, while *BufSize* should provide only an upper-bound on a possible buffer size. This flexibility allows for variable spatial grid sizes to result in smaller messages sent when appropriate. **To avoid MPI issues, it is very important that BufSize be pessimistic, provide an upper bound, and return the same value across processors.**

In general, the buffer should be self-contained. The receiving processor should be able to pull all necessary information from the buffer in order to properly interpret and unpack the buffer.

```
{
   *size_ptr = sizeof(double);
  return 0;
int
my_BufPack(braid_App
          braid_Vector u,
          void
                      *buffer,
          braid_Int
                     *size_ptr)
  double *dbuffer = buffer;
  dbuffer[0] = (u->value);
  *size_ptr = sizeof(double);
  return 0:
int
my_BufUnpack(braid_App
                        app,
            void *buffer,
            braid_Vector *u_ptr)
  double
            *dbuffer = buffer;
  my_Vector *u;
  u = (my_Vector *) malloc(sizeof(my_Vector));
   (u->value) = dbuffer[0];
  *u_ptr = u;
  return 0;
```

9. Coarsen, Restrict (optional): These are advanced options that allow for coarsening in space while you coarsen in time. This is useful for maintaining stable explicit schemes on coarse time scales and is not needed here. See for instance examples/drive-04 and examples/drive-05 which use these routines.

These functions allow you vary the spatial mesh size on XBraid levels as depicted here where the spatial and temporal grid sizes are halved every level.



10. Adaptive and variable time stepping is in the works to be implemented. The *rfactor* parameter in *Phi* will allow this.

Running XBraid

A typical flow of events in the main function is to first initialize the app structure.

```
/* set up app structure */
app = (my_App *) malloc(sizeof(my_App));
(app->comm) = comm;
(app->tstart) = tstart;
(app->tstop) = tstop;
(app->ntime) = ntime;
```

Then, the data structure definitions and wrapper routines are passed to XBraid. The core structure is used by XBraid for internal data structures.

3 Example 17

Then, XBraid options are set.

```
braid_SetPrintLevel( core, 1);
braid_SetMaxLevels(core, max_levels);
braid_SetNRelax(core, -1, nrelax);
braid_SetAbsTol(core, tol);
braid_SetCFactor(core, -1, cfactor);
braid_SetMaxIter(core, max_iter);
```

Then, the simulation is run.

```
braid_Drive(core);
```

Then, we clean up.

```
braid_Destroy(core);
```

Finally, to run drive-01, type

```
drive-01 - ml 5
```

This will run drive-01. See examples/drive-0* for more extensive examples.

Testing XBraid

The best overall test for XBraid, is to set the maximum number of levels to 1 (see braid_SetMaxLevels) which will carry out a sequential time stepping test. Take the output given to you by your *Access* function and compare it to output from a non-XBraid run. Is everything OK? Once this is complete, repeat for multilevel XBraid, and check that the solution is correct (that is, it matches a serial run to within tolerance).

At a lower level, to do sanity checks of your data structures and wrapper routines, there are also XBraid test functions, which can be easily run. The test routines also take as arguments the app structure, spatial communicator comm_x, a stream like stdout for test output and a time step size to test dt. After these arguments, function pointers to wrapper routines are the rest of the arguments. Some of the tests can return a boolean variable to indicate correctness.

```
/* Test init(), access(), free() */
braid_TestInitAccess( app, comm_x, stdout, dt, my_Init, my_Access, my_Free);
/* Test clone() */
braid_TestClone( app, comm_x, stdout, dt, my_Init, my_Access, my_Free, my_Clone);
/* Test sum() */
braid_TestSum( app, comm_x, stdout, dt, my_Init, my_Access, my_Free, my_Clone, my_Sum);
/* Test spatialnorm() */
correct = braid_TestSpatialNorm( app, comm_x, stdout, dt, my_Init, my_Free, my_Clone,
                          my_Sum, my_SpatialNorm);
/* Test bufsize(), bufpack(), bufunpack() */
correct = braid_TestBuf( app, comm_x, stdout, dt, my_Init, my_Free, my_Sum, my_SpatialNorm,
                    my_BufSize, my_BufPack, my_BufUnpack);
/* Test coarsen and refine */
correct = braid_TestCoarsenRefine(app, comm_x, stdout, 0.0, dt, 2*dt, my_Init,
                       my_Access, my_Free, my_Clone, my_Sum, my_SpatialNorm,
                       my_CoarsenInjection, my_Refine);
\texttt{correct = braid\_TestCoarsenRefine(app, comm\_x, stdout, 0.0, dt, 2*dt, my\_Init,}
                      my_Access, my_Free, my_Clone, my_Sum, my_SpatialNorm,
                      my_CoarsenBilinear, my_Refine);
```

4 Building XBraid

- Copyright information and licensing restrictions can be found in the files COPYRIGHT and LICENSE.
- To specify the compilers, flags and options for your machine, edit makefile.inc. For now, we keep it simple and avoid using configure or cmake.
- · To make the library, libbraid.a,

```
$ make
```

· To make the examples

```
$ make all
```

· The makefile lets you pass some parameters like debug with

```
$ make debug=yes

or
$ make all debug=yes
```

It would also be easy to add additional parameters, e.g., to compile with insure.

• To set compilers and library locations, look in makefile.inc where you can set up an option for your machine to define simple stuff like

```
CC = mpicc
MPICC = mpicc
MPICXX = mpiCC
LFLAGS = -lm
```

5 Compiling and running the examples

Type

```
drive-0* -help
```

for instructions on how to run any driver.

To run the examples, type

```
mpirun -np 4 drive-* [args]
```

- 1. drive-01 is the simplest example. It implements a scalar ODE and can be compiled and run with no outside dependencies.
- 2. drive-02 implements the 2D heat equation on a regular grid. You must have hypre installed and these variables in examples/Makefile set correctly

```
HYPRE_DIR = ../../linear_solvers/hypre
HYPRE_FLAGS = -I$(HYPRE_DIR)/include
HYPRE_LIB = -L$(HYPRE_DIR)/lib -lHYPRE
```

- 3. drive-03 implements the 3D heat equation on a regular grid, and assumes hypre is installed just like drive-02.
- 4. drive-05 implements the 2D heat equation on a regular grid, but it uses spatial coarsening. This allows you to use explicit time stepping on each Braid level, regardless of time step size. It assumes hypre is installed just like drive-02.
- 5. drive-04 is a sophisticated test bed for various PDEs, mostly parabolic. It relies on the mfem package to create general finite element discretizations for the spatial problem. Other packages must be installed in this order.
 - Unpack and install Metis
 - Unpack and install hypre
 - Unpack and install mfem. Make the serial version of mfem first by only typing make. Then make sure to set these variables correctly in the mfem Makefile:

```
USE_METIS_5 = YES
HYPRE_DIR = where_ever_linear_solvers_is/hypre
```

Make GLVIS, which needs serial mfem. Set these variables in the glvis makefile

6 Coding Style 19

```
MFEM_DIR = mfem_location
MFEM_LIB = -L$ (MFEM_DIR) -lmfem
```

Go back to the mfem directory and type

```
make clean
make parallel
```

Go to braid/examples and set these Makefile variables,

```
METIS_DIR = ../../metis-5.1.0/lib
MFEM_DIR = ../../mfem
MFEM_FLAGS = -I$(MFEM_DIR)
MFEM_LIB = -L$(MFEM_DIR) -lmfem -L$(METIS_DIR) -lmetis
then type
make drive-04
```

· To run drive-04 and glvis, open two windows. In one, start a glvis session

```
./glvis
Then, in the other window, run drive-04
mpirun -np ... drive-04 [args]
```

Glvis will listen on a port to which drive-04 will dump visualization information.

6 Coding Style

Code should follow the ellemtel style. See braid/misc/sample_c_code.c, and for emacs and vim style files, see braid/misc/sample.vimrc, and braid/misc/sample.emacs.

7 Using Doxygen

To build the documentation, doxygen must be version 1.8 or greater. XBraid documentation uses a markdown syntax both in source file comments and in *.md files.

To make the documentation,

```
$ make user_manual
$ acroread user_manual.pdf
```

or to make a more extensive reference manual for developers,

```
$ make developer_manual
$ acroread developer_manual.pdf
```

Developers can run doxygen from a precompiled binary, which may or may not work for your machine,

```
/usr/casc/hypre/braid/share/doxygen/bin/doxygen
```

or build doxygen from

```
/usr/casc/hypre/braid/share/doxygen.tgz
```

- Compiling doxygen requires a number of dependencies like Bison, GraphViz and Flex. Configure will tell you
 what you're missing
- Unpack doxygen.tgz, then from the doxygen directory
 ./configure --prefix some_dir_in_your_path
 make
 make install

Documentation Strategy

- The doxygen comments are to be placed in the header files.
- A sample function declaration using the documenation approach using markdown (including typesetting equations) is in braid.h for the function braid_Init()
- A sample structure documentation is in _braid.h for _braid_Core_struct
- Descriptors for files can also be added, as at the top of braid.h
- The Doxygen manual is at http://www.stack.nl/~dimitri/doxygen/manual/index.html

XBraid Doxygen details

The user and developer manuals are ultimately produced by Latex. The formatting of the manuals is configured according to the following.

- docs/local doxygen.sty
 - Latex style file used
- · docs/user manual header.tex
 - User manual title page and header info
- · docs/developer manual header.tex
 - Developer manual title page and header info
- *.md
 - Any file ending in .md is extra documentation in markdown format, like Introduction.md or the various Readme.md files in each directory. This material can be read in plain-text or when it's compiled by Doxygen and Latex.
- · docs/user_manual.conf
 - Doxygen configure file for the user manual
 - The FILE_NAMES tag is a filter to only include the user interface routines in braid.h
 - The INPUT tag orders the processing of the files and hence the section ordering
- docs/reference_manual.conf
 - Same as user_manual.conf, but the FILE_NAMES tag does not exclude any file from processing.
- · docs/img
 - Contains the images
- To regenerate generic doxygen latex files, type

```
$ doxygen -w latex header.tex footer.tex doxygen.sty doxy.conf
```

If this is done, then the .conf file must be changed to use the new header file and to copy the local_doxygen.sty file to the latex directory.

8 Regression Testing

Overview

- There are three levels in the testing framework. At each level, the fine-grain output from a testscript.sh is dumped into a directory testscript.dir, with the standard out and error stored in testscript.out and testscript.err. The test testscript.sh passes if testscript.err is empty (nothing is written to standard error).
- · Basic instructions: run a test with a command like

8 Regression Testing 21

```
$ ./test.sh diffusion2D.sh
```

Then, see if diffusion2D.err is of size 0. If it is not, look at it's contents to see which test failed.

- To add a new regression test, create a new lowest level script like diffusion2D.sh and then call it from a machine script at level 2.
- Regression tests should be run before pushing code. It is recommended to run the basic (lowest level) tests like diffusion2d.sh or machine test like machine-tux.sh

Lowest Level Test Scripts

As an example, here we look at one of the lowest level tests, the diffusion2d test.

Files used:

- test.sh
- diffusion2D.sh
- diffusion2D.saved

Output:

- diffusion2D.dir
- diffusion2D.err
- diffusion2D.out

At this level, we execute

```
$ ./test.sh diffusion2D.sh
```

or just

```
$ ./diffusion2D.sh
```

The script diffusion2D.sh must create diffusion2D.dir and place all fine-grain test output in this directory. test.sh captures the standard out and error in diffusion2D.out and diffusion2D.err. The test diffusion2D.sh passes if diffusion2D.err is empty (nothing is written to standard error).

The strategy for low level scripts like diffusion2D.sh is to run a sequence of test drivers such as

```
\ mpirun -np 1 ../examples/drive-02 -pgrid 1 1 1 -nt 256 \ mpirun -np 4 ../examples/drive-02 -pgrid 1 1 4 -nt 256
```

The output from the first mpirun test must then be written to files named

```
diffusion2D.dir/unfiltered.std.out.0
diffusion2D.dir/std.out.0
diffusion2D.dir/std.err.0
```

and the second mpirun test similarly writes the files

```
diffusion2D.dir/unfiltered.std.out.1
diffusion2D.dir/std.out.1
diffusion2D.dir/std.err.1
```

Subsequent tests are written to higher numbered files. The unfiltered.std.out.num file contains all of the standard out for the test, while std.out.num contains filtered output (usually from a grep command) and could

contain the output lines such as iteration numbers and number of levels. The file std.err.num contains the standard error output.

To see if a test ran correctly, std.out.num is compared to saved output in diffusion2D.saved. The file diffusion2D.saved contains the concatenated output from all the tests that diffusion2D.sh will run. For the above example, this file could look like

```
# Begin Test 1
number of levels = 6
iterations = 16
# Begin Test 2
number of levels = 4
iterations = 8
```

This saved output is split into an individual file for each test (using # Begin Test as a delimiter) and these new files are placed in diffusion2D.dir. So, after running these two regression tests, diffusion2D.dir will contain

```
diffusion2D.saved.0
diffusion2D.saved.1
unfiltered.std.out.0
std.out.0
std.err.0
unfiltered.std.out.1
std.out.1
std.err.1
```

An individual test has passed if std.err.num is empty. The file std.err.num contains a diff between diffusion2D.save.num and std.out.num (the diff ignores whitespace and the delimiter # Begin Test). Last in the directy where you ran ./test.sh diffusion2d.sh, the files

```
diffusion2D.err
diffusion2D.out
```

will be created. If all the tests passed then diffusion2D.err will be empty. Otherwise, it will contain the filenames of the std.err.num files that are non-empty, representing failed tests.

Level 2 Scripts

As an example, here we look at one of the Level 2 tests, the machine-tux test that Jacob runs.

Files used:

• machine-tux.sh

Output:

- machine-tux.dir
- machine-tux.err (only generated if autotest.sh is used to run machine-tux.sh)
- machine-tux.out (only generated if autotest.sh is used to run machine-tux.sh)

At this level, we execute

```
./machine-tux.sh
```

The autotest framework (autotest.sh) calls machine scripts in this way. Each machine script should be short and call lower-level scripts like diffusion2D.sh. The output from lower-level scripts must be moved to machine-tux.dir like this:

8 Regression Testing 23

```
$ ./test.sh diffusion2D.sh
$ mv -f diffusion2D.dir machine-tux.dir
$ mv -f diffusion2D.out machine-tux.dir
$ mv -f diffusion2D.err machine-tux.dir
```

All error files from diffusion2D.sh will be placed in machine-tux.dir, so if machine-tux.dir has all zero *.err files, then the machine-tux test has passed.

To begin testing on a new machine, like vulcan, add a new machine script similar to machine-tux.sh and change autotest.sh to recognize and run the new machine test. To then use autotest.sh with the machine script, you'll have to set up a passwordless connection from the new machine to

```
/usr/casc/hypre/braid/testing
```

Level 3 Script

Here we look at the highest level, where autotest.sh runs all of the level 2 machine tests and emails out the results.

Files used:

• autotest.sh

Output:

- test/autotest_finished
- /usr/casc/hypre/braid/testing/AUTOTEST-20**.**.**-Day
- Email to recipients listed in autotest.sh

At the highest level sits autotest.sh and is called automatically as a cronjob. If you just want to check to see if you've broken anything with a commit, just use lower level scripts.

There are four steps to running autotest.

```
    Step 1
```

```
$ ./autotesh.sh -init
```

will do a pull from master for the current working repository and recompile Braid. The autotest output files (autotest.err and autotest.out) and the output directory (autotest_finished) are initialized.

Step 2

```
$ ./autotest.sh -tux343
```

will run the autotests on tux343. This command will look for a machine-tux.sh, and execute it, moving the resulting

```
machine-tux.dir
machine-tux.err
machine-tux.out
```

into test/autotest_finished.

Step 3

```
$ ./autotest.sh -remote-copy
```

will copy /test/autotest_finished/* to a time-stamped directory such as /usr/casc/hypre/braid/testing/AUTOTEST-2013.11.18-Mon Alternatively,

```
$ ./autotesh.sh -remote-copy tux343
```

will ssh through tux343 to copy to /usr/casc. Multiple machines may independently be running regression tests and then copy to AUTOTEST-2013.11.18-Mon.

Step 4

```
$ ./autotest.sh -summary-email
```

will email everyone listed in the \$email_list (an autotest.sh variable)

Cronfile

To add entries to your crontab, First, put your new cronjob lines into cronfile. Then see what you already have in your crontab file with

```
$ crontab -1
```

Next, append to cronfile whatever you already have

```
$ crontab -l >> cronfile
```

Finally, tell crontab to use your cronfile

```
$ crontab cronfile
```

Then make sure it took affect with

```
$ crontab -1
```

Crontab entry format uses '*' to mean "every" and '*/m' to mean "every m-th". The first five entries on each line correspond respectively to:

- minute (0-56)
- hour (0-23)
- day of month (1-31)
- month (1-12)
- day of week (0-6)(0=Sunday)

Jacob's crontab (on tux343):

```
00 01 * * * source /etc/profile; source $HOME/.bashrc; cd $HOME/joint_repos/braid/test; ./autotest.sh -init
10 01 * * * source /etc/profile; source $HOME/.bashrc; cd $HOME/joint_repos/braid/test; ./autotest.sh -tux343
40 01 * * * source /etc/profile; source $HOME/.bashrc; cd $HOME/joint_repos/braid/test; ./autotest.sh -remote-composition of the source /etc/profile; source $HOME/.bashrc; cd $HOME/joint_repos/braid/test; ./autotest.sh -summary-composition of the source /etc/profile; source $HOME/.bashrc; cd $HOME/joint_repos/braid/test; ./autotest.sh -create-test.
```

9 Module Index

9.1 Modules

Here is a list of all modules:

User-written routines	
User interface routines	29
General Interface routines	30
XBraid status routines	38
XBraid test routines	46

10 Data Structure Index 25

1(n	Data	Structu	re Index
		Dala	JUUGIU	IC IIIUCA

braid AccessStatus

1	0.	1	П	ata	Str	116	٠tı	ires
	u.		ш	ala	JUL	u	, LL	1169

Here are	the data	structures	with	brief	descriptions

_braid_AccuracyHandle	51
_braid_CoarsenRefStatus	52
_braid_CommHandle	53
_braid_Core	54
_braid_Grid	58
_braid_PhiStatus	6 1

51

70

11 File Index

11.1 File List

Here is a list of all files with brief descriptions:

_braid.h Define headers for developer routines	61
braid.h	
Define headers for user interface routines	66
braid_defs.h	
Definitions of types, error flags, etc	68
braid_status.h	
Define headers for XBraid status structures, status get/set routines and status create/destroy rou-	
tines	69
braid_test.h	
Define headers for XBraid test routines	70
util b	

12 Module Documentation

12.1 User-written routines

Typedefs

• typedef struct _braid_App_struct * braid_App

Define headers for utility routines

- typedef struct _braid_Vector_struct * braid_Vector
- typedef braid_Int(* braid_PtFcnPhi)(braid_App app, braid_Vector u, braid_PhiStatus status)
- typedef braid_Int(* braid_PtFcnInit)(braid_App app, braid_Real t, braid_Vector *u_ptr)
- typedef braid Int(* braid PtFcnClone)(braid App app, braid Vector u, braid Vector *v ptr)
- typedef braid_Int(* braid_PtFcnFree)(braid_App app, braid_Vector u)
- typedef braid_Int(* braid_PtFcnSum)(braid_App app, braid_Real alpha, braid_Vector x, braid_Real beta, braid_Vector y)
- typedef braid_Int(* braid_PtFcnSpatialNorm)(braid_App app, braid_Vector u, braid_Real *norm_ptr)
- typedef braid_Int(* braid_PtFcnAccess)(braid_App app, braid_Vector u, braid_AccessStatus status)
- typedef braid_Int(* braid_PtFcnBufSize)(braid_App app, braid_Int *size_ptr)
- typedef braid_Int(* braid_PtFcnBufPack)(braid_App app, braid_Vector u, void *buffer, braid_Int *size_ptr)
- typedef braid_Int(* braid_PtFcnBufUnpack)(braid_App app, void *buffer, braid_Vector *u_ptr)
- typedef braid_Int(* braid_PtFcnCoarsen)(braid_App app, braid_Vector fu, braid_Vector *cu_ptr, braid_Coarsen-RefStatus status)
- typedef braid_Int(* braid_PtFcnRefine)(braid_App app, braid_Vector cu, braid_Vector *fu_ptr, braid_Coarsen-RefStatus status)

12.1.1 Detailed Description

These are all user-written data structures and routines. There are two data structures (braid_App and braid_Vector) for the user to define. And, there are a variety of function interfaces (defined through function pointer declarations) that the user must implement.

12.1.2 Typedef Documentation

12.1.2.1 typedef struct _braid_App_struct* braid_App

This holds a wide variety of information and is <code>global</code> in that it is passed to every function. This structure holds everything that the user will need to carry out a simulation. For a simple example, this could just hold the global MPI communicator and a few values describing the temporal domain.

12.1.2.2 typedef braid Int(* braid PtFcnAccess)(braid App app,braid Vector u,braid AccessStatus status)

Gives user access to XBraid and to the current vector u at time t. Most commonly, this lets the user write the vector to screen, file, etc... The user decides what is appropriate. Note how you are told the time value t of the vector u and other information in *status*. This lets you tailor the output, e.g., for only certain time values at certain XBraid iterations. Querrying status for such information is done through $braid_AccessStatusGet**(..)$ routines.

The frequency of XBraid's calls to *access* is controlled through <u>braid_SetAccessLevel</u>. For instance, if access_level is set to 2, then *access* is called every XBraid iteration and on every XBraid level. In this case, querrying *status* to determine the current XBraid level and iteration will be useful. This scenario allows for even more detailed tracking of the simulation.

Eventually, access will be broadened to allow the user to steer XBraid.

12.1.2.3 typedef braid_Int(* braid_PtFcnBufPack)(braid_App app,braid_Vector u,void *buffer,braid_Int *size_ptr)

This allows XBraid to send messages containing braid_Vectors. This routine packs a vector u into a *void* * *buffer* for MPI.

12.1 User-written routines 27

12.1.2.4 typedef braid Int(* braid PtFcnBufSize)(braid App app,braid Int *size_ptr)

This routine tells XBraid message sizes by computing an upper bound in bytes for an arbitrary braid_Vector. This size must be an upper bound for what BufPack and BufUnPack will assume.

12.1.2.5 typedef braid Int(* braid_PtFcnBufUnpack)(braid_App app,void *buffer,braid_Vector *u_ptr)

This allows XBraid to receive messages containing braid_Vectors. This routine unpacks a *void* * *buffer* from MPI into a braid_Vector.

12.1.2.6 typedef braid_Int(* braid_PtFcnClone)(braid_App app,braid_Vector u,braid_Vector *v_ptr)

Clone *u* into *v_ptr*

12.1.2.7 typedef braid_Int(* braid_PtFcnCoarsen)(braid_App app,braid_Vector fu,braid_Vector *cu_ptr,braid_CoarsenRefStatus status)

Spatial coarsening (optional). Allows the user to coarsen when going from a fine time grid to a coarse time grid. This function is called on every vector at each level, thus you can coarsem the entire space time domain. The action of this function should match the braid_PtFcnRefine function.

The user should query the status structure at run time with <code>braid_CoarsenRefGet**()</code> calls in order to determine how to coarsen. For instance, status tells you what the current time value is, and what the time step sizes on the fine and coarse levels are.

12.1.2.8 typedef braid_Int(* braid_PtFcnFree)(braid_App app,braid_Vector u)

Free and deallocate u

12.1.2.9 typedef braid Int(* braid PtFcnInit)(braid App app,braid Real t,braid Vector *u_ptr)

Initializes a vector *u_ptr* at time *t*

12.1.2.10 typedef braid_Int(* braid_PtFcnPhi)(braid_App app,braid_Vector u,braid_PhiStatus status)

Defines the central time stepping function that the user must write. The user must advance the vector *u* from time *tstart* to time *tstop*.

Query the status structure with <code>braid_PhiStatusGetTstart(status, &tstart)</code> and <code>braid_PhiStatusGetTstop(status, &tstop)</code> to get <code>tstart</code> and <code>tstop</code>. The status structure also allows for steering. For example, <code>braid_PhiStatusSetRFactor(...)</code> allows for setting rfactor, which tells XBraid to refine this time interval.

12.1.2.11 typedef braid_Int(* braid_PtFcnRefine)(braid_App app,braid_Vector cu,braid_Vector *fu_ptr,braid CoarsenRefStatus status)

Spatial refinement (optional). Allows the user to refine when going from a coarse time grid to a fine time grid. This function is called on every vector at each level, thus you can refine the entire space time domain. The action of this function should match the braid PtFcnCoarsen function.

The user should query the status structure at run time with <code>braid_CoarsenRefGet**()</code> calls in order to determine how to coarsen. For instance, status tells you what the current time value is, and what the time step sizes on the fine and coarse levels are.

12.1.2.12 typedef braid Int(* braid_PtFcnSpatialNorm)(braid_App app,braid_Vector u,braid_Real *norm_ptr)

Carry out a spatial norm by taking the norm of a braid_Vector $norm_ptr = ||u||$ A common choice is the standard Eucliden norm, but many other choices are possible, such as an L2-norm based on a finite element space. See braid_SetTemporalNorm for information on how the spatial norm is combined over time for a global space-time residual norm.

This global norm then controls halting.

12.1.2.13 typedef braid_Int(* braid_PtFcnSum)(braid_App app,braid_Real alpha,braid_Vector x,braid_Real beta,braid_Vector y)

AXPY, alpha x + beta y -> y

12.1.2.14 typedef struct _braid_Vector_struct* braid_Vector

This defines (roughly) a state vector at a certain time value. It could also contain any other information related to this vector which is needed to evolve the vector to the next time value, like mesh information.

Generated on Tue Nov 12 2013 12:07:46 for Braid by Doxygen

12.2 User interface routines

Modules

- General Interface routines
- XBraid status routines

12.2.1 Detailed Description

These are all the user interface routines.

12.3 General Interface routines

Typedefs

typedef struct braid Core struct * braid Core

Functions

- braid_Int braid_Init (MPI_Comm comm_world, MPI_Comm comm, braid_Real tstart, braid_Real tstop, braid_Int ntime, braid_App app, braid_PtFcnPhi phi, braid_PtFcnInit init, braid_PtFcnClone clone, braid_PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnAccess access, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack, braid_Core *core_ptr)
- braid Int braid Drive (braid Core core)
- · braid Int braid Destroy (braid Core core)
- braid_Int braid_PrintStats (braid_Core core)
- braid_Int braid_SetLoosexTol (braid_Core core, braid_Int level, braid_Real loose_tol)
- braid_Int braid_SetTightxTol (braid_Core core, braid_Int level, braid_Real tight_tol)
- braid_Int braid_SetMaxLevels (braid_Core core, braid_Int max_levels)
- braid Int braid SetMinCoarse (braid Core core, braid Int min coarse)
- braid Int braid SetAbsTol (braid Core core, braid Real atol)
- braid_Int braid_SetRelTol (braid_Core core, braid_Real rtol)
- braid Int braid SetNRelax (braid Core core, braid Int level, braid Int nrelax)
- braid Int braid SetCFactor (braid Core core, braid Int level, braid Int cfactor)
- braid_Int braid_SetMaxIter (braid_Core core, braid_Int max_iter)
- braid Int braid SetFMG (braid Core core)
- braid Int braid SetTemporalNorm (braid Core core, braid Int tnorm)
- braid Int braid SetNFMGVcyc (braid Core core, braid Int nfmg Vcyc)
- braid Int braid SetSpatialCoarsen (braid Core core, braid PtFcnCoarsen coarsen)
- braid Int braid SetSpatialRefine (braid Core core, braid PtFcnRefine refine)
- braid_Int braid_SetPrintLevel (braid_Core core, braid_Int print_level)
- braid_Int braid_SetPrintFile (braid_Core core, const char *printfile_name)
- braid_Int braid_SetAccessLevel (braid_Core core, braid_Int access_level)
- braid_Int braid_SplitCommworld (const MPI_Comm *comm_world, braid_Int px, MPI_Comm *comm_x, MPI_-Comm *comm t)
- braid_Int braid_GetNumIter (braid_Core core, braid_Int *niter_ptr)
- braid_Int braid_GetRNorm (braid_Core core, braid_Real *rnorm_ptr)

12.3.1 Detailed Description

These are general interface routines, e.g., routines to initialize and run a XBraid solver, or to split a communicator into spatial and temporal components.

12.3.2 Typedef Documentation

12.3.2.1 typedef struct _braid_Core_struct* braid Core

points to the core structure defined in _braid.h

12.3.3 Function Documentation

12.3.3.1 braid_Int braid_Destroy (braid_Core core)

Clean up and destroy core.

Parameters

core	braid_Core (_braid_Core) struct	
------	---------------------------------	--

12.3.3.2 braid_Int braid_Drive (braid_Core core)

Carry out a simulation with XBraid. Integrate in time.

Parameters

core	braid_Core (_braid_Core) struct

12.3.3.3 braid_Int braid_GetNumlter (braid_Core core, braid_Int * niter_ptr)

After Drive() finishes, this returns the number of iterations taken.

Parameters

core	braid_Core (_braid_Core) struct
niter_ptr	output, holds number of iterations taken

12.3.3.4 braid Int braid_GetRNorm (braid Core core, braid Real * rnorm_ptr)

After Drive() finishes, this returns the last measured residual norm.

Parameters

core	braid_Core (_braid_Core) struct
rnorm_ptr	output, holds final residual norm

12.3.3.5 braid_Int braid_Init (MPI_Comm comm_world, MPI_Comm comm, braid_Real tstart, braid_Real tstop, braid_Int ntime, braid_App app, braid_PtFcnPhi phi, braid_PtFcnInit init, braid_PtFcnClone clone, braid_PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnAccess access, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack, braid_Core * core_ptr)

Create a core object with the required initial data.

This core is used by XBraid for internal data structures. The output is *core_ptr* which points to the newly created braid Core structure.

Parameters

comm_world	Global communicator for space and time
comm	Communicator for temporal dimension
tstart	start time
tstop	End time
ntime	Initial number of temporal grid values
арр	User-defined _braid_App structure
phi	User time stepping routine to advance a braid_Vector forward one step
init	Initialize a braid_Vector on the finest temporal grid

clone	Clone a braid_Vector
free	Free a braid_Vector
sum	Compute vector sum of two braid_Vectors
spatialnorm	Compute norm of a braid_Vector, this is a norm only over space
access	Allows access to XBraid and current braid_Vector
bufsize	Computes size for MPI buffer for one braid_Vector
bufpack	Packs MPI buffer to contain one braid_Vector
bufunpack	Unpacks MPI buffer into a braid_Vector
core_ptr	Pointer to braid_Core (_braid_Core) struct

12.3.3.6 braid Int braid_PrintStats (braid Core core)

Print statistics after a XBraid run.

Parameters

core	braid_Core (_braid_Core) struct

12.3.3.7 braid_Int braid_SetAbsTol (braid_Core core, braid_Real atol)

Set absolute stopping tolerance.

Recommended option over relative tolerance

Parameters

core	braid_Core (_braid_Core) struct
atol	absolute stopping tolerance

12.3.3.8 braid_Int braid_SetAccessLevel (braid_Core core, braid_Int access_level)

Set access level for XBraid. This controls how often the user's access routine is called.

- · Level 0: Never call the user's access routine
- · Level 1: Only call the user's access routine after XBraid is finished
- Level 2: Call the user's access routine every iteration and on every level. This is during _braid_FRestrict, during the down-cycle part of a XBraid iteration.

Default is level 1.

Parameters

core	braid_Core (_braid_Core) struct
access_level	desired access_level

12.3.3.9 braid_Int braid_SetCFactor (braid_Core core, braid_Int level, braid_Int cfactor)

Set the coarsening factor *cfactor* on grid *level* (level 0 is the finest grid). The default factor is 2 on all levels. To change the default factor, use level = -1.

Parameters

core	braid_Core (_braid_Core) struct
level	level to set coarsening factor on
cfactor	desired coarsening factor

12.3.3.10 braid_Int braid_SetFMG (braid_Core core)

Once called, XBraid will use FMG (i.e., F-cycles.

Parameters

core	braid_Core (_braid_Core) struct

12.3.3.11 braid Int braid_SetLoosexTol (braid Core core, braid Int level, braid Real loose_tol)

Set loose stopping tolerance loose_tol for spatial solves on grid level (level 0 is the finest grid).

Parameters

	core	braid_Core (_braid_Core) struct
	level	level to set loose_tol
Ì	loose_tol	tolerance to set

12.3.3.12 braid_Int braid_SetMaxIter (braid_Core core, braid_Int max_iter)

Set max number of multigrid iterations.

Parameters

core	braid_Core (_braid_Core) struct
max_iter	maximum iterations to allow

12.3.3.13 braid_Int braid_SetMaxLevels (braid_Core core, braid_Int max_levels)

Set max number of multigrid levels.

Parameters

core	braid_Core (_braid_Core) struct
max_levels	maximum levels to allow

12.3.3.14 braid_Int braid_SetMinCoarse (braid_Core core, braid_Int min_coarse)

Set minimum allowed coarse grid size. XBraid stops coarsening whenever creating the next coarser grid will result in a grid smaller than min_coarse. The maximum possible coarse grid size will be min_coarse*coarsening_factor.

Parameters

core	braid_Core (_braid_Core) struct
min_coarse	minimum coarse grid size

12.3.3.15 braid_Int braid_SetNFMGVcyc (braid_Core core, braid_Int nfmg_Vcyc)

Set number of V-cycles to use at each FMG level (standard is 1)

Parameters

core	braid_Core (_braid_Core) struct
nfmg_Vcyc	number of V-cycles to do each FMG level

12.3.3.16 braid Int braid SetNRelax (braid Core core, braid Int level, braid Int nrelax)

Set the number of relaxation sweeps nrelax on grid level (level 0 is the finest grid). The default is 1 on all levels. To change the default factor, use level = -1. One sweep is a CF relaxation sweep.

Parameters

core	braid_Core (_braid_Core) struct
level	level to set nrelax on
nrelax	number of relaxations to do on level

12.3.3.17 braid_Int braid_SetPrintFile (braid_Core core, const char * printfile_name)

Set output file for runtime print messages. Level of printing is controlled by braid_SetPrintLevel. Default is stdout.

Parameters

core	braid_Core (_braid_Core) struct
printfile_name	output file for XBraid runtime output

12.3.3.18 braid_Int braid_SetPrintLevel (braid_Core core, braid_Int print_level)

Set print level for XBraid. This controls how much information is printed to the XBraid print file (braid SetPrintFile).

- · Level 0: no output
- Level 1: print typical information like a residual history, number of levels in the XBraid hierarchy, and so on.
- Level 2: level 1 output, plus debug level output.

Default is level 1.

Parameters

core	braid_Core (_braid_Core) struct
print_level	desired print level

12.3.3.19 braid Int braid_SetRelTol (braid Core core, braid Real rtol)

Set relative stopping tolerance, relative to the initial residual. Be careful. If your initial guess is all zero, then the initial residual may only be nonzero over one or two time values, and this will skew the relative tolerance. Absolute tolerances are recommended.

Parameters

core	braid_Core (_braid_Core) struct
rtol	relative stopping tolerance

12.3.3.20 braid Int braid_SetSpatialCoarsen (braid Core core, braid PtFcnCoarsen coarsen)

Set spatial coarsening routine with user-defined routine. Default is no spatial refinment or coarsening.

Parameters

core	braid_Core (_braid_Core) struct
coarsen	function pointer to spatial coarsening routine

12.3.3.21 braid Int braid SetSpatialRefine (braid Core core, braid PtFcnRefine refine)

Set spatial refinement routine with user-defined routine. Default is no spatial refinment or coarsening.

Parameters

core	braid_Core (_braid_Core) struct
refine	function pointer to spatial refinement routine

12.3.3.22 braid_Int braid_SetTemporalNorm (braid_Core core, braid_Int tnorm)

Sets XBraid temporal norm.

This option determines how to obtain a global space-time residual norm. That is, this decides how to combine the spatial norms returned by braid_PtFcnSpatialNorm at each time step to obtain a global norm over space and time. It is this global norm that then controls halting.

There are three options for setting *tnorm*. See section Halting tolerance for a more detailed discussion (in Introduction.-md).

- tnorm=1: One-norm summation of spatial norms
- tnorm=2: Two-norm summation of spatial norms
- tnorm=3: Infinity-norm combination of spatial norms

The default choice is tnorm=2

Parameters

core	braid_Core (_braid_Core) struct
tnorm	choice of temporal norm

12.3.3.23 braid_Int braid_SetTightxTol (braid_Core core, braid_Int level, braid_Real tight_tol)

Set tight stopping tolerance *tight_tol* for spatial solves on grid *level* (level 0 is the finest grid).

Parameters

core	braid_Core (_braid_Core) struct
level	level to set tight_tol
tight_tol	tolerance to set

12.3.3.24 braid_Int braid_SplitCommworld (const MPI_Comm * comm_world, braid_Int px, MPI_Comm * comm_x, MPI_Comm * comm_t)

Split MPI commworld into $comm_x$ and $comm_t$, the spatial and temporal communicators. The total number of processors will equal Px*Pt, there Px is the number of procs in space, and Pt is the number of procs in time.

Parameters

comm_world	Global communicator to split
рх	Number of processors parallelizing space for a single time step
comm_x	Spatial communicator (written as output)
comm_t	Temporal communicator (written as output)

12.4 XBraid status routines

Data Structures

- struct braid AccessStatus
- · struct braid CoarsenRefStatus
- · struct braid PhiStatus

Macros

• #define braid StatusElt(status, elt) ((status) -> elt)

Typedefs

- typedef struct
 _braid_AccessStatus_struct * braid_AccessStatus
- typedef struct
 _braid_CoarsenRefStatus_struct * braid_CoarsenRefStatus
- typedef struct
 braid PhiStatus struct * braid PhiStatus

Functions

- braid_Int _braid_AccessStatusInit (braid_Real t, braid_Real rnorm, braid_Int iter, braid_Int level, braid_Int done, braid_Int wrapper_test, braid_AccessStatus status)
- braid Int braid AccessStatusDestroy (braid AccessStatus status)
- braid Int braid AccessStatusGetT (braid AccessStatus status, braid Real *t ptr)
- braid Int braid AccessStatusGetResidual (braid AccessStatus status, braid Real *rnorm ptr)
- braid_Int braid_AccessStatusGetIter (braid_AccessStatus status, braid_Int *iter_ptr)
- braid Int braid AccessStatusGetLevel (braid AccessStatus status, braid Int *level ptr)
- braid Int braid AccessStatusGetDone (braid AccessStatus status, braid Int *done ptr)
- braid Int braid AccessStatusGetWrapperTest (braid AccessStatus status, braid Int *wtest ptr)
- braid_Int braid_AccessStatusGetTILD (braid_AccessStatus status, braid_Real *t_ptr, braid_Int *iter_ptr, braid_Int *level_ptr, braid_Int *done_ptr)
- braid_Int_braid_CoarsenRefStatusInit (braid_Real tstart, braid_Real f_tprior, braid_Real f_tstop, braid_Real c_tprior, braid_Real c_tstop, braid_CoarsenRefStatus status)
- braid_Int _braid_CoarsenRefStatusDestroy (braid_CoarsenRefStatus status)
- braid Int braid CoarsenRefStatusGetTstart (braid CoarsenRefStatus status, braid Real *tstart ptr)
- braid Int braid CoarsenRefStatusGetFTstop (braid CoarsenRefStatus status, braid Real *f tstop ptr)
- braid Int braid CoarsenRefStatusGetFTprior (braid CoarsenRefStatus status, braid Real *f tprior ptr)
- braid_Int braid_CoarsenRefStatusGetCTstop (braid_CoarsenRefStatus status, braid_Real *c_tstop_ptr)
- braid_Int braid_CoarsenRefStatusGetCTprior (braid_CoarsenRefStatus status, braid_Real *c_tprior_ptr)
- braid_Int braid_CoarsenRefStatusGetTpriorTstop (braid_CoarsenRefStatus status, braid_Real *tstart_ptr, braid_Real *f_tstop_ptr, braid_Real *c_tstop_ptr, braid_Real *c_tstop_ptr)
- braid_Int _braid_PhiStatusInit (braid_Real tstart, braid_Real tstop, braid_Real accuracy, braid_PhiStatus status)
- braid_Int _braid_PhiStatusDestroy (braid_PhiStatus status)
- braid_Int braid_PhiStatusGetTstart (braid_PhiStatus status, braid_Real *tstart_ptr)
- braid_Int braid_PhiStatusGetTstop (braid_PhiStatus status, braid_Real *tstop_ptr)
- braid_Int braid_PhiStatusGetAccuracy (braid_PhiStatus status, braid_Real *accuracy_ptr)
- braid Int braid PhiStatusSetRFactor (braid PhiStatus status, braid Real rfactor)
- braid Int braid PhiStatusGetTstartTstop (braid PhiStatus status, braid Real *tstart ptr, braid Real *tstop ptr)

12.4.1 Detailed Description

XBraid status structures are what tell the user the status of the simulation when their routines (phi, coarsen/refine, access) are called.

12.4.2 Macro Definition Documentation

12.4.2.1 #define _braid_StatusElt(status, elt) ((status) -> elt)

Accessor for all braid**Status attributes

12.4.3 Typedef Documentation

12.4.3.1 typedef struct _braid_AccessStatus_struct* braid_AccessStatus

The user access routine will receive braid_AccessStatus, which will be a pointer to the actual _braid_AccessStatus_struct

12.4.3.2 typedef struct _braid_CoarsenRefStatus_struct* braid_CoarsenRefStatus

The user coarsen and refine routines will receive braid_CoarsenRefStatus, which will be a pointer to the actual _braid_CoarsenRefStatus_struct

12.4.3.3 typedef struct _braid_PhiStatus_struct* braid_PhiStatus

The user's phi routine will receive braid PhiStatus, which will be a pointer to the actual braid PhiStatus struct

12.4.4 Function Documentation

12.4.4.1 braid Int_braid_AccessStatusDestroy (braid AccessStatus status)

Destroy a braid_AccessStatus structurestructure to be destroyed

12.4.4.2 braid_Int_braid_AccessStatusInit (braid_Real t, braid_Real rnorm, braid_Int iter, braid_Int level, braid_Int done, braid_Int wrapper_test, braid_AccessStatus status)

Initialize a braid AccessStatus structure

Parameters

t	current time
rnorm	current residual norm in XBraid
iter	current iteration in XBraid
level	current level in XBraid
done	boolean describing whether XBraid has finished
wrapper_test	boolean describing whether this call is only a wrapper test
status	structure to initialize

12.4.4.3 braid Int_braid_CoarsenRefStatusDestroy (braid CoarsenRefStatus status)

Destroy a braid_CoarsenRefStatus structurestructure to be destroyed

12.4.4.4 braid_Int_braid_CoarsenRefStatusInit (braid_Real tstart, braid_Real f_tprior, braid_Real f_tstop, braid_Real c_tstop, braid_CoarsenRefStatus status)

Initialize a braid_CoarsenRefStatus structure

Parameters

tstart	time value for current vector
f_tprior	time value to the left of tstart on fine grid
f_tstop	time value to the right of tstart on fine grid
c_tprior	time value to the left of tstart on coarse grid
c_tstop	time value to the right of tstart on coarse grid
status	structure to initialize

12.4.4.5 braid_Int _braid_PhiStatusDestroy (braid_PhiStatus status)

Destroy a braid_PhiStatus structurestructure to be destroyed

12.4.4.6 braid_Int_braid_PhiStatusInit (braid_Real tstart, braid_Real tstop, braid_Real accuracy, braid_PhiStatus status)

Initialize a braid PhiStatus structure

Parameters

tstart	current time value
tstop	time value to evolve towards, time value to the right of tstart
accuracy	advanced option allowing variable accuracy for implicit phi
status	structure to initialize

12.4.4.7 braid_Int braid_AccessStatusGetDone (braid_AccessStatus status, braid_Int * done_ptr)

Return whether XBraid is done for the current simulation.

done_ptr = 1 indicates that XBraid has finished iterating, (either maxiter has been reached, or the tolerance has been met).

Parameters

status	structure containing current simulation info
done_ptr	output, =1 if XBraid has finished, else =0

12.4.4.8 braid_Int braid_AccessStatusGetIter (braid_AccessStatus status, braid_Int * iter_ptr)

Return the current iteration from the AccessStatus structure.

Parameters

status	structure containing current simulation info
iter_ptr	output, current XBraid iteration number

12.4.4.9 braid_Int braid_AccessStatusGetLevel (braid_AccessStatus status, braid_Int * level_ptr)

Return the current XBraid level from the AccessStatus structure.

Parameters

status	structure containing current simulation info

level_ptr	output, current level in XBraid
-----------	---------------------------------

12.4.4.10 braid_Int braid_AccessStatusGetResidual (braid_AccessStatus status, braid_Real * rnorm_ptr)

Return the current residual norm from the AccessStatus structure.

Parameters

status	structure containing current simulation info
rnorm_ptr	output, current residual norm

12.4.4.11 braid_Int braid_AccessStatusGetT (braid_AccessStatus status, braid_Real * t_ptr)

Return the current time from the AccessStatus structure.

Parameters

status	structure containing current simulation info
t_ptr	output, current time

12.4.4.12 braid_Int braid_AccessStatusGetTILD (braid_AccessStatus status, braid_Real * t_ptr, braid_Int * iter_ptr, braid_Int * done_ptr)

Return XBraid status for the current simulation. Four values are returned.

TILD: time, iteration, level, done

These values are also available through individual Get routines. These individual routines are the location of detailed documentation on each parameter, e.g., see *braid_AccessStatusGetDone* for more information on the *done* value.

Parameters

status	structure containing current simulation info
t_ptr	output, current time
iter_ptr	output, current iteration in XBraid
level_ptr	output, current level in XBraid
done_ptr	output, boolean describing whether XBraid has finished

12.4.4.13 braid_Int braid_AccessStatusGetWrapperTest (braid_AccessStatus status, braid_Int * wtest_ptr)

Return whether this is a wrapper test or an XBraid run

Parameters

status	structure containing current simulation info
wtest_ptr	output, =1 if this is a wrapper test, =0 if XBraid run

12.4.4.14 braid_Int braid_CoarsenRefStatusGetCTprior (braid_CoarsenRefStatus status, braid_Real * c_tprior_ptr)

Return the coarse grid time value to the left of the current time value from the CoarsenRefStatus structure.

Parameters

Generated on Tue Nov 12 2013 12:07:46 for Braid by Doxygen

status	structure containing current simulation info
c_tprior_ptr	output, time value to the left of current time value on coarse grid

12.4.4.15 braid_Int braid_CoarsenRefStatusGetCTstop (braid_CoarsenRefStatus status, braid_Real * c_tstop_ptr)

Return the coarse grid time value to the right of the current time value from the CoarsenRefStatus structure.

Parameters

status	structure containing current simulation info
c_tstop_ptr	output, time value to the right of current time value on coarse grid

12.4.4.16 braid Int braid_CoarsenRefStatusGetFTprior (braid CoarsenRefStatus status, braid Real * f_tprior_ptr)

Return the fine grid time value to the left of the current time value from the CoarsenRefStatus structure.

Parameters

status	structure containing current simulation info
f_tprior_ptr	output, time value to the left of current time value on fine grid

12.4.4.17 braid_Int braid_CoarsenRefStatusGetFTstop (braid_CoarsenRefStatus status, braid_Real * f_tstop_ptr)

Return the fine grid time value to the right of the current time value from the CoarsenRefStatus structure.

Parameters

status	structure containing current simulation info
f_tstop_ptr	output, time value to the right of current time value on fine grid

12.4.4.18 braid_Int braid_CoarsenRefStatusGetTpriorTstop (braid_CoarsenRefStatus status, braid_Real * tstart_ptr, braid_Real * f_tstop_ptr, braid_Real * c_tstop_ptr, braid_Real * c_tstop_ptr)

Return XBraid status for the current simulation. Five values are returned, tstart, f_tprior, f_tstop, c_tprior, c_tstop.

These values are also available through individual Get routines. These individual routines are the location of detailed documentation on each parameter, e.g., see *braid_CoarsenRefStatusGetCTprior* for more information on the *c_tprior* value.

Parameters

status	structure containing current simulation info
tstart_ptr	output, time value current vector
f_tprior_ptr	output, time value to the left of tstart on fine grid
f_tstop_ptr	output, time value to the right of tstart on fine grid
c_tprior_ptr	output, time value to the left of tstart on coarse grid
c_tstop_ptr	output, time value to the right of tstart on coarse grid

12.4.4.19 braid_Int braid_CoarsenRefStatusGetTstart (braid_CoarsenRefStatus status, braid_Real * tstart_ptr)

Return the current time value from the CoarsenRefStatus structure.

Parameters

status	structure containing current simulation info
tstart_ptr	output, current time

12.4.4.20 braid Int braid PhiStatusGetAccuracy (braid PhiStatus status, braid Real * accuracy ptr)

Return the current accuracy value, usually between 0 and 1.0, which can allow for tuning of implicit solve accuracy

Parameters

	status	structure containing current simulation info
Ī	accuracy_ptr	output, current accuracy value

12.4.4.21 braid_Int braid_PhiStatusGetTstart (braid_PhiStatus status, braid_Real * tstart_ptr)

Return the current time value from the PhiStatus structure.

Parameters

status	structure containing current simulation info
tstart_ptr	output, current time

12.4.4.22 braid_Int braid_PhiStatusGetTstartTstop (braid_PhiStatus status, braid_Real * tstart_ptr, braid_Real * tstop_ptr)

Return XBraid status for the current simulation. Two values are returned, tstart and tstop.

These values are also available through individual Get routines. These individual routines are the location of detailed documentation on each parameter, e.g., see *braid_PhiStatusGetTstart* for more information on the *tstart* value.

Parameters

status	structure containing current simulation info
tstart_ptr	output, current time
tstop_ptr	output, next time value to evolve towards

12.4.4.23 braid_Int braid_PhiStatusGetTstop (braid_PhiStatus status, braid_Real * tstop_ptr)

Return the time value to the right of the current time value from the PhiStatus structure.

Parameters

status	structure containing current simulation info
tstop_ptr	output, next time value to evolve towards

12.4.4.24 braid Int braid_PhiStatusSetRFactor (braid PhiStatus status, braid Real rfactor)

Set the rfactor, a desired refinement factor for this interval. rfactor=1 indicates no refinement, otherwise, this inteval is subdivided rfactor times.

Parameters

Generated on Tue Nov 12 2013 12:07:46 for Braid by Doxygen

status	structure containing current simulation info
rfactor	user-determined desired rfactor

12.5 XBraid test routines

Functions

braid_Int braid_TestInitAccess (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free)

- braid_Int braid_TestClone (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone)
- braid_Int braid_TestSum (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid PtFcnFree free, braid PtFcnClone clone, braid PtFcnSum sum)
- braid_Int braid_TestSpatialNorm (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid PtFcnFree free, braid PtFcnClone clone, braid PtFcnSum sum, braid PtFcnSpatialNorm spatialnorm)
- braid_Int braid_TestBuf (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_-PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_-PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack)
- braid_Int braid_TestCoarsenRefine (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_Real fdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnCoarsen coarsen, braid_PtFcnRefine refine)
- braid_Int braid_TestAll (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_Real fdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack, braid_PtFcnCoarsen coarsen, braid_PtFcnRefine refine)

12.5.1 Detailed Description

These are sanity check routines to help a user test their XBraid code.

12.5.2 Function Documentation

12.5.2.1 braid_Int braid_TestAll (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_Real fdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack, brai

Runs all of the individual braid Test* routines

- · Returns 0 if the tests fail
- · Returns 1 if the tests pass
- · Check the log messages to see details of which tests failed.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages

t	Time value to initialize test vectors with
fdt	Fine time step value that you spatially coarsen from
cdt	Coarse time step value that you coarsen to
init	Initialize a braid_Vector on finest temporal grid
free	Free a braid_Vector
clone	Clone a braid_Vector
sum	Compute vector sum of two braid_Vectors
spatialnorm	Compute norm of a braid_Vector, this is a norm only over space
bufsize	Computes size in bytes for one braid_Vector MPI buffer
bufpack	Packs MPI buffer to contain one braid_Vector
bufunpack	Unpacks MPI buffer into a braid_Vector
coarsen	Spatially coarsen a vector. If NULL, test is skipped.
refine	Spatially refine a vector. If NULL, test is skipped.

12.5.2.2 braid_Int braid_TestBuf (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack)

Test the BufPack, BufUnpack and BufSize functions.

A vector is initialized at time *t*, packed into a buffer, then unpacked from a buffer. The unpacked result must equal the original vector.

- · Returns 0 if the tests fail
- · Returns 1 if the tests pass
- · Check the log messages to see details of which tests failed.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t	Time value to test Buffer routines (used to initialize the vectors)
init	Initialize a braid_Vector on finest temporal grid
free	Free a braid_Vector
sum	Compute vector sum of two braid_Vectors
spatialnorm	Compute norm of a braid_Vector, this is a norm only over space
bufsize	Computes size in bytes for one braid_Vector MPI buffer
bufpack	Packs MPI buffer to contain one braid_Vector
bufunpack	Unpacks MPI buffer containing one braid_Vector

12.5.2.3 braid_Int braid_TestClone (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone)

Test the clone function.

A vector is initialized at time *t*, cloned, and both vectors are written. Then both vectors are free-d. The user is to check (via the access function) to see if it is identical.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t	Time value to test clone with (used to initialize the vectors)
init	Initialize a braid_Vector on finest temporal grid
access	Allows access to XBraid and current braid_Vector (can be NULL for no writing)
free	Free a braid_Vector
clone	Clone a braid_Vector

12.5.2.4 braid_Int braid_TestCoarsenRefine (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_Real tdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnCoarsen coarsen, braid_PtFcnRefine refine)

Test the Coarsen and Refine functions.

A vector is initialized at time t, and various sanity checks on the spatial coarsening and refinement routines are run.

- · Returns 0 if the tests fail
- · Returns 1 if the tests pass
- Check the log messages to see details of which tests failed.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t	Time value to initialize test vectors
fdt	Fine time step value that you spatially coarsen from
cdt	Coarse time step value that you coarsen to
init	Initialize a braid_Vector on finest temporal grid
access	Allows access to XBraid and current braid_Vector (can be NULL for no writing)
free	Free a braid_Vector
clone	Clone a braid_Vector
sum	Compute vector sum of two braid_Vectors
spatialnorm	Compute norm of a braid_Vector, this is a norm only over space
coarsen	Spatially coarsen a vector
refine	Spatially refine a vector

12.5.2.5 braid_Int braid_TestInitAccess (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free)

Test the init, access and free functions.

A vector is initialized at time t, written, and then free-d

Parameters

12.5 XBraid test routines 49

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t	Time value to test init with (used to initialize the vectors)
init	Initialize a braid_Vector on finest temporal grid
access	Allows access to XBraid and current braid_Vector (can be NULL for no writing)
free	Free a braid_Vector

12.5.2.6 braid_Int braid_TestSpatialNorm (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm)

Test the spatialnorm function.

A vector is initialized at time t and then cloned. Various norm evaluations like || 3 v || / || v || with known output are then done.

- · Returns 0 if the tests fail
- Returns 1 if the tests pass
- Check the log messages to see details of which tests failed.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t	Time value to test SpatialNorm with (used to initialize the vectors)
init	Initialize a braid_Vector on finest temporal grid
free	Free a braid_Vector
clone	Clone a braid_Vector
sum	Compute vector sum of two braid_Vectors
spatialnorm	Compute norm of a braid_Vector, this is a norm only over space

12.5.2.7 braid_Int braid_TestSum (braid_App app, MPI_Comm comm_x, FILE * fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum)

Test the sum function.

A vector is initialized at time *t*, cloned, and then these two vectors are summed a few times, with the results written. The vectors are then free-d. The user is to check (via the access function) that the output matches the sum of the two original vectors.

Parameters

арр	User defined App structure
comm_x	Spatial communicator
fp	File pointer (could be stdout or stderr) for log messages
t Time value to test Sum with (used to initialize the vectors)	
init	Initialize a braid_Vector on finest temporal grid

access	Allows access to XBraid and current braid_Vector (can be NULL for no writing)
free	Free a braid_Vector
clone	Clone a braid_Vector
sum	Compute vector sum of two braid_Vectors

13 Data Structure Documentation

13.1 _braid_AccessStatus Struct Reference

Data Fields

- braid_Real t
- · braid Int iter
- · braid Int level
- braid Real rnorm
- braid_Int done
- braid_Int wrapper_test

13.1.1 Detailed Description

AccessStatus structure which defines the status of XBraid at a given instant on some level during a run. The user accesses it through <code>braid_AccessStatusGet**()</code> functions.

13.1.2 Field Documentation

13.1.2.1 braid_Int done

boolean describing whether XBraid has finished

13.1.2.2 braid Int iter

XBraid iteration number

13.1.2.3 braid_Int level

current level in XBraid

13.1.2.4 braid Real rnorm

residual norm

13.1.2.5 braid_Real t

current time

13.1.2.6 braid_Int wrapper_test

boolean describing whether this call is only a wrapper test

The documentation for this struct was generated from the following file:

· braid_status.h

13.2 _braid_AccuracyHandle Struct Reference

Data Fields

· braid_Int matchF

- · braid Real value
- · braid Real old value
- · braid Real loose
- braid_Real tight
- · braid_Int tight_used

13.2.1 Detailed Description

XBraid Accuracy Handle, used for controlling the accuracy of solves during implicit time stepping. For instance, to do less accurate solves on coarse time grids

13.2.2 Field Documentation

13.2.2.1 braid_Real loose

loose accuracy for spatial solves

13.2.2.2 braid Int matchF

13.2.2.3 braid_Real old_value

old accuracy value used in FRestrict

13.2.2.4 braid_Real tight

tight accuracy for spatial solves

13.2.2.5 braid Int tight_used

tight accuracy used (1) or not (0)

13.2.2.6 braid_Real value

accuracy value

The documentation for this struct was generated from the following file:

• _braid.h

13.3 _braid_CoarsenRefStatus Struct Reference

Data Fields

- · braid Real tstart
- braid_Real f_tprior
- braid_Real f_tstop
- · braid_Real c_tprior
- · braid_Real c_tstop

13.3.1 Detailed Description

The user coarsen and refine routines will receive a CoarsenRefStatus structure, which defines the status of XBraid at a given instant of coarsening or refinement on some level during a run. The user accesses it through <code>braid_CoarsenRef-StatusGet**()</code> functions.

13.3.2 Field Documentation

13.3.2.1 braid Real c_tprior

time value to the left of tstart on coarse grid

13.3.2.2 braid_Real c_tstop

time value to the right of tstart on coarse grid

13.3.2.3 braid_Real f_tprior

time value to the left of tstart on fine grid

13.3.2.4 braid_Real f_tstop

time value to the right of tstart on fine grid

13.3.2.5 braid_Real tstart

current time value

The documentation for this struct was generated from the following file:

braid_status.h

13.4 _braid_CommHandle Struct Reference

Data Fields

- braid_Int request_type
- braid_Int num_requests
- MPI Request * requests
- MPI_Status * status
- void * buffer
- braid_Vector * vector_ptr

13.4.1 Detailed Description

XBraid comm handle structure

Used for initiating and completing nonblocking communication to pass braid Vectors between processors.

13.4.2 Field Documentation

13.4.2.1 void* buffer

Buffer for message

13.4.2.2 braid_Int num_requests

number of active requests for this handle, usually 1

13.4.2.3 braid Int request_type

two values: recv type = 1, and send type = 0

13.4.2.4 MPI_Request* requests

MPI request structure

13.4.2.5 MPI_Status* status

MPI status

13.4.2.6 braid_Vector* vector_ptr

braid_vector being sent/received

The documentation for this struct was generated from the following file:

• _braid.h

13.5 braid Core Struct Reference

Data Fields

- · MPI Comm comm world
- MPI Comm comm
- · braid_Real tstart
- · braid_Real tstop
- braid_Int ntime
- braid_App app
- · braid_PtFcnPhi phi
- · braid_PtFcnInit init
- braid_PtFcnClone clone
- braid_PtFcnFree free
- braid_PtFcnSum sum
- braid_PtFcnSpatialNorm spatialnorm
- braid_PtFcnAccess access
- braid_PtFcnBufSize bufsize
- braid_PtFcnBufPack bufpack
- · braid PtFcnBufUnpack bufunpack
- braid_PtFcnCoarsen coarsen
- braid_PtFcnRefine refine
- braid_Int access_level
- braid_Int print_level
- braid_Int max_levels

- · braid Int min coarse
- · braid Real tol
- braid Int rtol
- braid Int * nrels
- braid_Int nrdefault
- braid_Int * cfactors
- · braid_Int cfdefault
- · braid_Int max_iter
- braid_Int niter
- · braid_Real rnorm
- braid_Int fmg
- braid Int nfmg Vcyc
- braid Int tnorm
- braid_Real * tnorm_a
- braid AccuracyHandle * accuracy
- braid_AccessStatus astatus
- braid CoarsenRefStatus cstatus
- braid_PhiStatus pstatus
- braid_Int gupper
- braid_Int * rfactors
- braid_Int nlevels
- _braid_Grid ** grids
- · braid_Real localtime
- braid_Real globaltime

13.5.1 Detailed Description

The typedef _braid_Core struct is a **critical** part of XBraid and is passed to *each* routine in XBraid. It thus allows each routine access to XBraid attributes.

13.5.2 Field Documentation

13.5.2.1 braid_PtFcnAccess access

user access function to XBraid and current vector

13.5.2.2 braid_Int access_level

determines how often to call the user's access routine

13.5.2.3 _braid_AccuracyHandle* accuracy

accuracy of spatial solves on different levels

13.5.2.4 braid_App app

application data for the user

13.5.2.5 braid AccessStatus astatus

status structure passed to user-written Access routine

```
13.5.2.6 braid PtFcnBufPack bufpack
pack a buffer
13.5.2.7 braid PtFcnBufSize bufsize
return buffer size
13.5.2.8 braid PtFcnBufUnpack bufunpack
unpack a buffer
13.5.2.9 braid_Int* cfactors
coarsening factors
13.5.2.10 braid_Int cfdefault
default coarsening factor
13.5.2.11 braid_PtFcnClone clone
clone a vector
13.5.2.12 braid_PtFcnCoarsen coarsen
(optional) return a coarsened vector
13.5.2.13 MPI_Comm comm
communicator for the time dimension
13.5.2.14 MPI Comm comm world
13.5.2.15 braid_CoarsenRefStatus cstatus
status structure passed to user-written coarsen/refine routines
13.5.2.16 braid_Int fmg
use FMG cycle
13.5.2.17 braid_PtFcnFree free
free up a vector
13.5.2.18 braid_Real globaltime
global wall time for <a href="mailto:braid_Drive">braid_Drive</a>()
13.5.2.19 _braid_Grid** grids
pointer to temporal grid structures for each level
13.5.2.20 braid_Int gupper
global upper index on the fine grid
```

13.5.2.21 braid PtFcnInit init return an initialized braid_Vector 13.5.2.22 braid_Real localtime local wall time for braid_Drive() 13.5.2.23 braid_Int max_iter maximum number of multigrid in time iterations 13.5.2.24 braid_Int max_levels maximum number of temporal grid levels 13.5.2.25 braid_Int min_coarse minimum possible coarse grid size 13.5.2.26 braid_Int nfmg_Vcyc number of V-cycle calls at each level in FMG 13.5.2.27 braid_Int niter number of iterations 13.5.2.28 braid Int nlevels number of temporal grid levels 13.5.2.29 braid Int nrdefault default number of pre-relaxations 13.5.2.30 braid Int* nrels number of pre-relaxations on each level 13.5.2.31 braid Int ntime initial number of time intervals 13.5.2.32 braid_PtFcnPhi phi apply phi function 13.5.2.33 braid_Int print_level determines amount of output printed to screem (0,1,2) 13.5.2.34 braid_PhiStatus pstatus

status structure passed to user-written phi routines

```
13.5.2.35 braid PtFcnRefine refine
(optional) return a refined vector
13.5.2.36 braid_Int* rfactors
refinement factors for finest grid (if any)
13.5.2.37 braid Real rnorm
residual norm
13.5.2.38 braid_Int rtol
use relative tolerance
13.5.2.39 braid_PtFcnSpatialNorm spatialnorm
Compute norm of a braid_Vector, this is a norm only over space
13.5.2.40 braid_PtFcnSum sum
vector sum
13.5.2.41 braid_Int tnorm
choice of temporal norm
13.5.2.42 braid_Real* tnorm_a
local array of residual norms on a proc's interval, used for inf-norm
13.5.2.43 braid_Real tol
stopping tolerance
13.5.2.44 braid Real tstart
start time
13.5.2.45 braid Real tstop
stop time
The documentation for this struct was generated from the following file:

    braid.h
```

13.6 _braid_Grid Struct Reference

Data Fields

- braid_Int level
- · braid_Int ilower
- · braid_Int iupper
- · braid_Int clower

- · braid Int cupper
- braid_Int gupper
- · braid_Int cfactor
- · braid_Int ncpoints
- braid_Vector * ua
- braid_Real * ta
- braid_Vector * va
- braid_Vector * wa
- braid_Int recv_index
- braid_Int send_index
- _braid_CommHandle * recv_handle
- _braid_CommHandle * send_handle
- braid_Vector * ua_alloc
- braid Real * ta alloc
- braid_Vector * va_alloc
- braid_Vector * wa_alloc

13.6.1 Detailed Description

XBraid Grid structure for a certain time level

Holds all the information for a processor related to the temporal grid at this level.

13.6.2 Field Documentation

13.6.2.1 braid_Int cfactor

coarsening factor

13.6.2.2 braid_Int clower

smallest C point index

13.6.2.3 braid_Int cupper

largest C point index

13.6.2.4 braid_Int gupper

global size of the grid

13.6.2.5 braid_Int ilower

smallest time index at this level

13.6.2.6 braid Intiupper

largest time index at this level

13.6.2.7 braid_Int level

Level that grid is on

```
13.6.2.8 braid Int ncpoints
number of C points
13.6.2.9 _braid_CommHandle* recv_handle
Handle for nonblocking receives of braid_Vectors
13.6.2.10 braid Int recv_index
-1 means no receive
13.6.2.11 _braid_CommHandle* send_handle
Handle for nonblocking sends of braid_Vectors
13.6.2.12 braid_Int send_index
-1 means no send
13.6.2.13 braid_Real* ta
time values (all points)
13.6.2.14 braid_Real* ta_alloc
original memory allocation for ta
13.6.2.15 braid_Vector* ua
unknown vectors (C-points only)
13.6.2.16 braid_Vector* ua_alloc
original memory allocation for ua
13.6.2.17 braid_Vector* va
restricted unknown vectors (all points, NULL on level 0)
13.6.2.18 braid Vector* va_alloc
original memory allocation for va
13.6.2.19 braid_Vector* wa
rhs vectors f-v (all points, NULL on level 0)
13.6.2.20 braid_Vector* wa_alloc
original memory allocation for wa
The documentation for this struct was generated from the following file:
```

• _braid.h

13.7 braid PhiStatus Struct Reference

Data Fields

- · braid Real tstart
- braid Real tstop
- · braid_Real accuracy
- · braid_Int rfactor

13.7.1 Detailed Description

The user's phi routine routine will receive a PhiStatus structure, which defines the status of XBraid at the given instant for phi evaluation on some level during a run. The user accesses it through *braid_PhiStatusGet**()* functions.

13.7.2 Field Documentation

13.7.2.1 braid_Real accuracy

advanced option allowing variable accuracy for implicit phi

```
13.7.2.2 braid_Int rfactor
```

if set by user, allows for subdivision of this interval for bettter time accuracy

13.7.2.3 braid Real tstart

current time value

13.7.2.4 braid_Real tstop

time value to evolve towards, time value to the right of tstart

The documentation for this struct was generated from the following file:

· braid_status.h

14 File Documentation

14.1 _braid.h File Reference

Data Structures

- struct braid CommHandle
- struct _braid_AccuracyHandle
- struct _braid_Grid
- struct _braid_Core

Macros

- #define _braid_CommHandleElt(handle, elt) ((handle) -> elt)
- #define _braid_GridElt(grid, elt) ((grid) -> elt)

- #define braid CoreElt(core, elt) ((core) -> elt)
- #define braid CoreFcn(core, fcn) (*((core) -> fcn))
- #define _braid_MapFineToCoarse(findex, cfactor, cindex) (cindex = (findex)/(cfactor))
- #define braid MapCoarseToFine(cindex, cfactor, findex) (findex = (cindex)*(cfactor))
- #define braid IsFPoint(index, cfactor) ((index)%(cfactor))
- #define braid IsCPoint(index, cfactor) (! braid IsFPoint(index, cfactor))

Functions

- braid_Int _braid_GetDistribution (braid_Core core, braid_Int *ilower_ptr, braid_Int *iupper_ptr)
- braid Int braid GetProc (braid Core core, braid Int level, braid Int index, braid Int *proc ptr)
- braid_Int _braid_CommRecvInit (braid_Core core, braid_Int level, braid_Int index, braid_Vector *vector_ptr, _braid_CommHandle **handle_ptr)
- braid_Int _braid_CommSendInit (braid_Core core, braid_Int level, braid_Int index, braid_Vector vector, _braid_-CommHandle **handle_ptr)
- braid Int braid CommWait (braid Core core, braid CommHandle **handle ptr)
- braid Int braid UCommInit (braid Core core, braid Int level)
- braid_Int _braid_UCommInitF (braid_Core core, braid_Int level)
- braid_Int _braid_UCommWait (braid_Core core, braid_Int level)
- braid_Int _braid_UGetInterval (braid_Core core, braid_Int level, braid_Int interval_index, braid_Int *flo_ptr, braid_Int *flo_ptr, braid_Int *ci_ptr)
- braid_Int _braid_UGetVectorRef (braid_Core core, braid_Int level, braid_Int index, braid_Vector *u_ptr)
- braid_Int _braid_USetVectorRef (braid_Core core, braid_Int level, braid_Int index, braid_Vector u)
- braid_Int _braid_UGetVector (braid_Core core, braid_Int level, braid_Int index, braid_Vector *u_ptr)
- braid_Int _braid_USetVector (braid_Core core, braid_Int level, braid_Int index, braid_Vector u)
- braid Int braid UAccessVector (braid Core core, braid AccessStatus status, braid Vector u)
- braid_Int_braid_Phi (braid_Core core, braid_Int level, braid_Int index, braid_Real accuracy, braid_Vector u, braid_Int *rfactor)
- braid Int braid Step (braid Core core, braid Int level, braid Int index, braid Real accuracy, braid Vector u)
- braid_Int _braid_Coarsen (braid_Core core, braid_Int level, braid_Int f_index, braid_Int c_index, braid_Vector fvector, braid_Vector *cvector)
- braid_Int _braid_Refine (braid_Core core, braid_Int level, braid_Int f_index, braid_Int c_index, braid_Vector cvector, braid_Vector *fvector)
- braid_Int _braid_GridInit (braid_Core core, braid_Int level, braid_Int ilower, braid_Int iupper, _braid_Grid **grid_ptr)
- braid Int braid_GridDestroy (braid_Core core, _braid_Grid *grid)
- braid Int braid InitGuess (braid Core core, braid Int level)
- braid Int braid FCRelax (braid Core core, braid Int level)
- braid_Int _braid_FRestrict (braid_Core core, braid_Int level, braid_Int iter, braid_Real *rnorm_ptr)
- braid Int braid FInterp (braid Core core, braid Int level, braid Int iter, braid Real rnorm)
- braid_Int _braid_FRefine (braid_Core core, braid_Int *refined_ptr)
- braid_Int _braid_FAccess (braid_Core core, braid_Real rnorm, braid_Int iter, braid_Int level, braid_Int done)
- braid Int braid InitHierarchy (braid Core core, braid Grid *fine grid)

Variables

• FILE * braid printfile

14.1.1 Detailed Description

Define headers for developer routines. This file contains the headers for developer routines.

```
14.1.2 Macro Definition Documentation
```

```
14.1.2.1 #define _braid_CommHandleElt( handle, elt ) ((handle) -> elt)
```

Accessor for braid CommHandle attributes

```
14.1.2.2 #define _braid_CoreElt( core, elt ) ( (core) -> elt )
```

Accessor for braid Core attributes

```
14.1.2.3 #define _braid_CoreFcn( core, fcn ) (*((core) -> fcn))
```

Accessor for <u>braid</u> Core functions

```
14.1.2.4 #define _braid_GridElt( grid, elt ) ((grid) -> elt)
```

Accessor for <u>braid</u> Grid attributes

```
14.1.2.5 #define _braid_IsCPoint( index, cfactor ) ( !_braid_IsFPoint(index, cfactor) )
```

Boolean, returns whether a time index is an C-point

```
14.1.2.6 #define _braid_IsFPoint( index, cfactor ) ( (index)%(cfactor) )
```

Boolean, returns whether a time index is an F-point

```
14.1.2.7 #define _braid_MapCoarseToFine( cindex, cfactor, findex ) ( findex = (cindex)*(cfactor) )
```

Map a coarse time index to a fine time index, assumes a uniform coarsening factor.

```
14.1.2.8 #define _braid_MapFineToCoarse( findex, cfactor, cindex ) ( cindex = (findex)/(cfactor) )
```

Map a fine time index to a coarse time index, assumes a uniform coarsening factor.

14.1.3 Function Documentation

```
14.1.3.1 braid_Int _braid_Coarsen ( braid_Core core, braid_Int level, braid_Int f_index, braid_Int c_index, braid_Vector fvector, braid_Vector * cvector )
```

Coarsen in space on *level* by calling the user's coarsen function. The vector corresponding to the time step index f_i index on the fine grid is coarsened to the time step index f_i index on the coarse grid. The output goes in *cvector* and the input vector is *fvector*.

```
14.1.3.2 braid_Int_braid_CommRecvInit ( braid_Core core, braid_Int level, braid_Int index, braid_Vector * vector_ptr, braid_CommHandle ** handle_ptr )
```

Initialize a receive to go into *vector_ptr* for the given time *index* on *level*. Also return a comm handle *handle_ptr* for querying later, to see if the receive has occurred.

```
14.1.3.3 braid_Int_braid_CommSendInit ( braid_Core core, braid_Int level, braid_Int index, braid_Vector vector, braid CommHandle ** handle ptr )
```

Initialize a send of *vector* for the given time *index* on *level*. Also return a comm handle *handle_ptr* for querying later, to see if the send has occurred.

14.1.3.4 braid Int_braid_CommWait (braid Core core, braid CommHandle ** handle_ptr)

Block on the comm handle *handle ptr* until the MPI operation (send or recv) has completed

14.1.3.5 braid Int_braid_FAccess (braid Core core, braid Real rnorm, braid Int iter, braid Int level, braid Int done)

Call the user's access function in order to give access to XBraid and the current vector at grid *level and iteration* **iter*. Most commonly, this lets the user write solutions to screen, disk, etc... The quantity *rnorm* denotes the last computed residual norm, and *done* is a boolean indicating whether XBraid has finished iterating and this is the last Access call.

14.1.3.6 braid_Int_braid_FCRelax (braid_Core core, braid_Int level)

Do nu sweeps of F-then-C relaxation on level

14.1.3.7 braid_Int _braid_Finterp (braid_Core core, braid_Int level, braid_Int iter, braid_Real rnorm)

F-Relax on level and interpolate to level-1

The output is set in the braid Grid in core, so that the vector u on level is created by interpolating from level+1.

If the user has set spatial refinement, then this user-defined routine is also called.

Parameters

core	braid_Core (_braid_Core) struct
level	interp from level to level+1
iter	current iteration number (for user info)
rnorm	residual norm (if level 0)

14.1.3.8 braid Int_braid_FRefine (braid_Core core, braid_Int * refined_ptr)

Create a new fine grid based on user refinement factor information, then F-relax and interpolate to the new fine grid and create a new multigrid hierarchy. In general, this will require load re-balancing as well.

RDF: Todo, routine is unwritten

14.1.3.9 braid_Int _braid_FRestrict (braid_Core core, braid_Int level, braid_Int iter, braid_Real * rnorm_ptr)

F-Relax on level and then restrict to level+1

The output is set in the braid_Grid in core, so that the restricted vectors *va* and *wa* will be created, representing *level+1* versions of the unknown and rhs vectors.

If the user has set spatial coarsening, then this user-defined routine is also called.

If level==0, then rnorm_ptr will contain the residual norm.

Parameters

core	braid_Core (_braid_Core) struct
level	restrict from level to level+1
iter	current iteration number (for user info)
rnorm_ptr	pointer to residual norm (if level 0)

14.1.3.10 braid_Int_braid_GetDistribution (braid_Core core, braid_Int * ilower_ptr, braid_Int * iupper_ptr)

Determine processor distribution. This must agree with GetProc(). For the processor rank calling this function, it returns the smallest and largest time indices (<code>ilower_ptr</code> and <code>iupper_ptr</code>) that belong to that processor (the indices may * be F or C points).

14.1.3.11 braid Int braid GetProc (braid Core core, braid Int level, braid Int index, braid Int * proc ptr)

Return the processor number in *proc_ptr* on which the time step *index* lives for the given *level.* * Returns -1 if *index* is out of range

14.1.3.12 braid Int_braid_GridDestroy (braid Core core, _braid_Grid * grid)

Destroy an XBraid grid

14.1.3.13 braid_Int_braid_GridInit (braid_Core core, braid_Int level, braid_Int ilower, braid_Int iupper, _braid_Grid ** grid_ptr)

Create a new grid object grid_ptr in core at level

ilower and iupper correspond to the lower and upper time index values for this processor on this grid.

14.1.3.14 braid Int_braid_InitGuess (braid Core core, braid Int level)

Set initial guess at C-points on level

14.1.3.15 braid Int_braid_InitHierarchy (braid Core core, braid Grid * fine_grid)

Initialize (and re-initialize) hierarchy

14.1.3.16 braid_Int_braid_Phi (braid_Core core, braid_Int level, braid_Int index, braid_Real accuracy, braid_Vector u, braid_Int * rfactor)

Apply Phi to the vector u

This is the vector corresponding to the time step *index* on *level. accuracy* is a user set variable to allow for tuning the accuracy of spatial solvesfor implicit stepping. And, *rfactor* allows the user to subdivide time intervals for accuracy purposes.

14.1.3.17 braid_Int_braid_Refine (braid_Core core, braid_Int level, braid_Int f_index, braid_Int c_index, braid_Vector cvector, braid_Vector * fvector)

Refine in space on *level* by calling the user's refine function. The vector corresponding to the time step index *c_index* on the coarse grid is refined to the time step index *f_index* on the fine grid. The output goes in *fvector* and the input vector is *cvector*.

14.1.3.18 braid_Int_braid_Step (braid_Core core, braid_Int level, braid_Int index, braid_Real accuracy, braid_Vector u)

Integrate one time step at time step index to time step index+1

14.1.3.19 braid Int_braid_UAccessVector(braid Core core, braid AccessStatus status, braid Vector u)

Call user's access function in order to give access to XBraid and the current vector. Most commonly, this lets the user write *u* to screen, disk, etc... The vector *u* corresponds to time step *index* on *level. status* holds state information about the current XBraid iteration, time value, etc...

14.1.3.20 braid Int_braid_UCommlnit (braid Core core, braid Int level)

Working on all intervals

At *level*, post a receive for the point to the left of ilower (regardless whether ilower is F or C). Then, post a send of iupper if iupper is a C point.

14.1.3.21 braid Int_braid_UCommlnitF (braid Core core, braid Int level)

Working only on F-pt intervals

At *level*, **only** post a receive for the point to the left of ilower if ilower is an F point. Then, post a send of iupper if iupper is a C point.

14.1.3.22 braid Int_braid_UCommWait (braid Core core, braid Int level)

Finish up communication

On level, wait on both the recv and send handles at this level.

14.1.3.23 braid_Int_braid_UGetInterval (braid_Core core, braid_Int level, braid_Int interval_index, braid_Int * flo_ptr, braid_Int * fhi_ptr, braid_Int * ci_ptr)

Retrieve the time step indices at this *level* which correspond to the FC interval given by *interval_index*. ci_ptr is the time step index for the C point and flo_ptr and fhi_ptr are the smallest and largest F point indices in this interval. flo = ci + 1, and fhi = ci + coarsening factor - 1

14.1.3.24 braid Int_braid_UGetVector (braid Core core, braid Int level, braid Int index, braid Vector * u_ptr)

Returns the u-vector in u_ptr on grid level at point index. If index is my "receive index" (as set by UCommInit(), for example), the u-vector will be received from a neighbor processor. If index is within my index range and is also a C-point, the saved value of u will be used. A NULL value is returned otherwise.

14.1.3.25 braid_Int_braid_UGetVectorRef (braid_Core core, braid_Int level, braid_Int index, braid_Vector * u_ptr)

Returns a reference to the local u-vector in *u_ptr* for the grid *level* at point *index*. Caveat: if *index* is not a C-point and within my index range, NULL is returned.

14.1.3.26 braid Int_braid_USetVector (braid Core core, braid Int level, braid Int index, braid Vector u)

Sets the u-vector on grid *level* at point *index*. If *index* is my "send index" (as set by UCommInit(), for example), a send is initiated to a neighbor processor. If *index* is within my index range and is also a C-point, the value is saved locally.

14.1.3.27 braid Int braid USetVectorRef (braid Core core, braid Int level, braid Int index, braid Vector u)

Stores a reference to the vector *u* on grid *level* at point *index*. If *index* is not a C-point and within this processor's range of time points, then nothing is done.

14.1.4 Variable Documentation

14.1.4.1 FILE* braid_printfile

This is the print file for redirecting stdout for all XBraid screen output

14.2 braid.h File Reference

Typedefs

- typedef struct braid App struct * braid App
- typedef struct _braid_Vector_struct * braid_Vector
- typedef braid_Int(* braid_PtFcnPhi)(braid_App app, braid_Vector u, braid_PhiStatus status)

- typedef braid Int(* braid PtFcnInit)(braid App app, braid Real t, braid Vector *u ptr)
- typedef braid_Int(* braid_PtFcnClone)(braid_App app, braid_Vector u, braid_Vector *v_ptr)
- typedef braid_Int(* braid_PtFcnFree)(braid_App app, braid_Vector u)
- typedef braid_Int(* braid_PtFcnSum)(braid_App app, braid_Real alpha, braid_Vector x, braid_Real beta, braid_Vector y)
- typedef braid Int(* braid PtFcnSpatialNorm)(braid App app, braid Vector u, braid Real *norm ptr)
- typedef braid_Int(* braid_PtFcnAccess)(braid_App app, braid_Vector u, braid_AccessStatus status)
- typedef braid Int(* braid PtFcnBufSize)(braid App app, braid Int *size ptr)
- typedef braid Int(* braid PtFcnBufPack)(braid App app, braid Vector u, void *buffer, braid Int *size ptr)
- typedef braid_Int(* braid_PtFcnBufUnpack)(braid_App app, void *buffer, braid_Vector *u_ptr)
- typedef braid_Int(* braid_PtFcnCoarsen)(braid_App app, braid_Vector fu, braid_Vector *cu_ptr, braid_Coarsen-RefStatus status)
- typedef braid_Int(* braid_PtFcnRefine)(braid_App app, braid_Vector cu, braid_Vector *fu_ptr, braid_Coarsen-RefStatus status)
- typedef struct braid Core struct * braid Core

Functions

- braid_Int braid_Init (MPI_Comm comm_world, MPI_Comm comm, braid_Real tstart, braid_Real tstop, braid_Int ntime, braid_App app, braid_PtFcnPhi phi, braid_PtFcnInit init, braid_PtFcnClone clone, braid_PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnAccess access, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack, braid_Core *core_ptr)
- braid_Int braid_Drive (braid_Core core)
- braid Int braid Destroy (braid Core core)
- braid Int braid PrintStats (braid Core core)
- braid_Int braid_SetLoosexTol (braid_Core core, braid_Int level, braid_Real loose_tol)
- braid Int braid SetTightxTol (braid Core core, braid Int level, braid Real tight tol)
- braid_Int braid_SetMaxLevels (braid_Core core, braid_Int max_levels)
- braid Int braid SetMinCoarse (braid Core core, braid Int min coarse)
- braid Int braid SetAbsTol (braid Core core, braid Real atol)
- braid Int braid SetRelTol (braid Core core, braid Real rtol)
- braid Int braid SetNRelax (braid Core core, braid Int level, braid Int nrelax)
- braid_Int braid_SetCFactor (braid_Core core, braid_Int level, braid_Int cfactor)
- braid_Int braid_SetMaxIter (braid_Core core, braid_Int max_iter)
- braid Int braid SetFMG (braid Core core)
- braid_Int braid_SetTemporalNorm (braid_Core core, braid_Int tnorm)
- braid_Int braid_SetNFMGVcyc (braid_Core core, braid_Int nfmg_Vcyc)
- braid Int braid SetSpatialCoarsen (braid Core core, braid PtFcnCoarsen coarsen)
- braid Int braid SetSpatialRefine (braid Core core, braid PtFcnRefine refine)
- braid Int braid SetPrintLevel (braid Core core, braid Int print level)
- braid Int braid SetPrintFile (braid Core core, const char *printfile name)
- braid_Int braid_SetAccessLevel (braid_Core core, braid_Int access_level)
- braid_Int braid_SplitCommworld (const MPI_Comm *comm_world, braid_Int px, MPI_Comm *comm_x, MPI_Comm *comm t)
- braid Int braid GetNumIter (braid Core core, braid Int *niter ptr)
- braid_Int braid_GetRNorm (braid_Core core, braid_Real *rnorm_ptr)

14.2.1 Detailed Description

Define headers for user interface routines. This file contains routines used to allow the user to initialize, run and get and set a XBraid solver.

14.3 braid defs.h File Reference

Macros

```
#define _braid_TAlloc(type, count) ( (type *)malloc((size_t)(sizeof(type) * (count))) )
```

- #define _braid_CTAlloc(type, count) ((type *)calloc((size_t)(count), (size_t)sizeof(type)))
- #define _braid_TReAlloc(ptr, type, count) ((type *)realloc((char *)ptr, (size_t)(sizeof(type) * (count))))
- #define _braid_TFree(ptr) (free((char *)ptr), ptr = NULL)

Typedefs

- typedef int braid Int
- typedef double braid_Real

Variables

• braid_Int _braid_error_flag

14.3.1 Detailed Description

Definitions of types, error flags, etc...

14.3.2 Macro Definition Documentation

```
14.3.2.1 #define _braid_CTAlloc( type, count ) ( (type *)calloc((size_t)(count), (size_t)sizeof(type)) )
```

Allocation macro

```
14.3.2.2 #define _braid_TAlloc( type, count ) ( (type *)malloc((size_t)(sizeof(type) * (count))) )
```

Allocation macro

```
14.3.2.3 #define _braid_TFree( ptr ) ( free((char *)ptr), ptr = NULL )
```

Free memory macro

```
14.3.2.4 #define_braid_TReAlloc( ptr, type, count ) ( (type *)realloc((char *)ptr, (size_t)(sizeof(type) * (count))) )
```

Re-allocation macro

14.3.3 Typedef Documentation

14.3.3.1 typedef int braid Int

Defines integer type

14.3.3.2 typedef double braid_Real

Defines floating point type

14.3.4 Variable Documentation

14.3.4.1 braid Int_braid_error_flag

This is the global XBraid error flag. If it is ever nonzero, an error has occurred.

14.4 braid_status.h File Reference

Data Structures

- struct braid AccessStatus
- struct braid CoarsenRefStatus
- · struct braid PhiStatus

Macros

#define braid StatusElt(status, elt) ((status) -> elt)

Typedefs

- typedef struct
 _braid_AccessStatus_struct * braid_AccessStatus
- typedef struct <u>braid_CoarsenRefStatus_struct * braid_CoarsenRefStatus</u>
- typedef struct
 _braid_PhiStatus_struct * braid_PhiStatus

Functions

- braid_Int _braid_AccessStatusInit (braid_Real t, braid_Real rnorm, braid_Int iter, braid_Int level, braid_Int done, braid Int wrapper test, braid AccessStatus status)
- braid_Int _braid_AccessStatusDestroy (braid_AccessStatus status)
- braid_Int braid_AccessStatusGetT (braid_AccessStatus status, braid_Real *t_ptr)
- braid Int braid AccessStatusGetResidual (braid AccessStatus status, braid Real *rnorm ptr)
- braid_Int braid_AccessStatusGetIter (braid_AccessStatus status, braid_Int *iter_ptr)
- braid_Int braid_AccessStatusGetLevel (braid_AccessStatus status, braid_Int *level_ptr)
- braid Int braid AccessStatusGetDone (braid AccessStatus status, braid Int *done ptr)
- braid Int braid AccessStatusGetWrapperTest (braid AccessStatus status, braid Int *wtest ptr)
- braid_Int braid_AccessStatusGetTILD (braid_AccessStatus status, braid_Real *t_ptr, braid_Int *iter_ptr, braid_-Int *level_ptr, braid_Int *done_ptr)
- braid_Int_braid_CoarsenRefStatusInit (braid_Real tstart, braid_Real f_tprior, braid_Real f_tstop, braid_Real c_tprior, braid_Real c_tstop, braid_CoarsenRefStatus status)
- braid_Int _braid_CoarsenRefStatusDestroy (braid_CoarsenRefStatus status)
- braid Int braid CoarsenRefStatusGetTstart (braid CoarsenRefStatus status, braid Real *tstart ptr)
- braid Int braid CoarsenRefStatusGetFTstop (braid CoarsenRefStatus status, braid Real *f tstop ptr)
- braid Int braid CoarsenRefStatusGetFTprior (braid CoarsenRefStatus status, braid Real *f tprior ptr)
- braid Int braid CoarsenRefStatusGetCTstop (braid CoarsenRefStatus status, braid Real *c tstop ptr)
- braid_Int braid_CoarsenRefStatusGetCTprior (braid_CoarsenRefStatus status, braid_Real *c_tprior_ptr)
- braid_Int braid_CoarsenRefStatusGetTpriorTstop (braid_CoarsenRefStatus status, braid_Real *tstart_ptr, braid_Real *f_tprior_ptr, braid_Real *c_tprior_ptr, braid_Real *c_tstop_ptr)

- braid Int braid PhiStatusInit (braid Real tstart, braid Real tstop, braid Real accuracy, braid PhiStatus status)
- braid Int braid PhiStatusDestroy (braid PhiStatus status)
- braid_Int braid_PhiStatusGetTstart (braid_PhiStatus status, braid_Real *tstart_ptr)
- braid Int braid PhiStatusGetTstop (braid PhiStatus status, braid Real *tstop ptr)
- braid Int braid PhiStatusGetAccuracy (braid PhiStatus status, braid Real *accuracy ptr)
- braid Int braid PhiStatusSetRFactor (braid PhiStatus status, braid Real rfactor)
- braid Int braid PhiStatusGetTstartTstop (braid PhiStatus status, braid Real *tstart ptr, braid Real *tstop ptr)

14.4.1 Detailed Description

Define headers for XBraid status structures, status get/set routines and status create/destroy routines.

14.5 braid_test.h File Reference

Functions

- braid_Int braid_TestInitAccess (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free)
- braid_Int braid_TestClone (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone)
- braid_Int braid_TestSum (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_ PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum)
- braid_Int braid_TestSpatialNorm (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm)
- braid_Int braid_TestBuf (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_PtFcnInit init, braid_-PtFcnFree free, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_-PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack)
- braid_Int braid_TestCoarsenRefine (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_Real fdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnAccess access, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnCoarsen coarsen, braid_PtFcnRefine refine)
- braid_Int braid_TestAll (braid_App app, MPI_Comm comm_x, FILE *fp, braid_Real t, braid_Real fdt, braid_Real cdt, braid_PtFcnInit init, braid_PtFcnFree free, braid_PtFcnClone clone, braid_PtFcnSum sum, braid_PtFcnSpatialNorm spatialnorm, braid_PtFcnBufSize bufsize, braid_PtFcnBufPack bufpack, braid_PtFcnBufUnpack bufunpack, braid_PtFcnCoarsen coarsen, braid_PtFcnRefine refine)

14.5.1 Detailed Description

Define headers for XBraid test routines. This file contains routines used to test a user's XBraid wrapper routines oneby-one.

14.6 util.h File Reference

Functions

- braid_Int _braid_ProjectInterval (braid_Int ilower, braid_Int iupper, braid_Int index, braid_Int stride, braid_Int *piupper)
- braid_Int _braid_SetAccuracy (braid_Real rnorm, braid_Real loose_tol, braid_Real tight_tol, braid_Real old-Accuracy, braid_Real tol, braid_Real *paccuracy)
- braid_Int _braid_printf (const char *format,...)

14.6 util.h File Reference 71

- braid Int braid ParFprintfFlush (FILE *file, braid Int myid, char *message,...)
- braid Int braid Max (braid Real *array, braid Int size, braid Real *max val)

14.6.1 Detailed Description

Define headers for utility routines. This file contains the headers for utility routines. Essentially, if a routine does not take braid Core (or other XBraid specific structs) as an argument, then it's a utility routine.

14.6.2 Function Documentation

```
14.6.2.1 braid_Int_braid_Max ( braid_Real * array, braid_Int size, braid_Real * max_val )
```

This function finds the maximum value in a braid Real array

```
14.6.2.2 braid_Int_braid_ParFprintfFlush (FILE * file, braid_Int myid, char * message, ... )
```

This is a function that allows for "sane" printing of information in parallel. Currently, only myid = 0 prints, but this can be updated as needs change.

The string message is printed and can be multiple parameters in the standard * C-format, like

```
message = '%1.2e is a format string', 1.24

14.6.2.3 braid_Int_braid_printf(const char * format, ...)
```

If set, print to braid printfile and then flush. Else print to standard out.

The string format can be multiple parameters in the standard * C-format, like

```
format = '%1.2e is a format string', 1.24
```

14.6.2.4 braid_Int _braid_ProjectInterval (braid_Int ilower, braid_Int iupper, braid_Int index, braid_Int stride, braid_Int * pilower, braid_Int * piupper)

Project an interval onto a strided index space that contains the index 'index' and has stride 'stride'. An empty projection is represented by ilower > iupper.

14.6.2.5 braid_Int_braid_SetAccuracy (braid_Real rnorm, braid_Real loose_tol, braid_Real tight_tol, braid_Real oldAccuracy, braid_Real tol, braid_Real * paccuracy)

Determine the accuracy used for the spatial solves based on the ratio of the current residual norm and the stopping tolerance.

Index

braid.h, 61	old value 52
-	old_value, 52
_braid_Coarsen, 63	tight, 52
_braid_CommHandleElt, 63	tight_used, 52
_braid_CommRecvInit, 63	value, 52
_braid_CommSendInit, 63	_braid_CTAlloc
_braid_CommWait, 63	braid_defs.h, 68
_braid_CoreElt, 63	_braid_Coarsen
_braid_CoreFcn, 63	_braid.h, 63
_braid_FAccess, 64	_braid_CoarsenRefStatus, 52
_braid_FCRelax, 64	c_tprior, 53
_braid_FInterp, 64	c_tstop, 53
_braid_FRefine, 64	f_tprior, 53
_braid_FRestrict, 64	f_tstop, 53
_braid_GetDistribution, 64	tstart, 53
_braid_GetProc, 64	_braid_CoarsenRefStatusDestroy
_braid_GridDestroy, 65	XBraid status routines, 39
_braid_GridElt, 63	_braid_CoarsenRefStatusInit
_braid_GridInit, 65	XBraid status routines, 39
_braid_InitGuess, 65	_braid_CommHandle, 53
_braid_InitHierarchy, 65	buffer, 53
_braid_IsCPoint, 63	num_requests, 54
_braid_IsFPoint, 63	request_type, 54
_braid_MapCoarseToFine, 63	requests, 54
_braid_MapFineToCoarse, 63	status, 54
_braid_Phi, 65	vector_ptr, 54
_braid_Refine, 65	_braid_CommHandleElt
_braid_Step, 65	_braid.h, 63
_braid_UAccessVector, 65	_braid_CommRecvInit
_braid_UCommInit, 65	_braid.h, 63
_braid_UCommInitF, 65	_braid_CommSendInit
_braid_UCommWait, 66	_braid.h, 63
_braid_UGetInterval, 66	_braid_CommWait
_braid_UGetVector, 66	_braid.h, 63
_braid_UGetVectorRef, 66	_braid_Core, 54
_braid_USetVector, 66	access, 55
_braid_USetVectorRef, 66	access_level, 55
_braid_printfile, 66	accuracy, 55
braid AccessStatus, 51	app, 55
done, 51	astatus, 55
iter, 51	bufpack, 55
level, 51	bufsize, 56
rnorm, 51	bufunpack, 56
t, 51	cfactors, 56
wrapper test, 51	cfdefault, 56
_braid_AccessStatusDestroy	clone, 56
XBraid status routines, 39	coarsen, 56
braid AccessStatusInit	comm, 56
XBraid status routines, 39	comm_world, 56
_braid_AccuracyHandle, 51	cstatus, 56
loose, 52	fmg, 56
matchF, 52	free, 56
, -	,

globaltime, 56	ncpoints, 59
grids, 56	recv_handle, 60
gupper, 56	recv_index, 60
init, 56	send_handle, 60
localtime, 57	send_index, 60
max_iter, 57	ta, 60
max_levels, 57	ta_alloc, 60
min_coarse, 57	ua, 60
nfmg Vcyc, 57	ua_alloc, 60
niter, 57	va, 60
nlevels, 57	va alloc, 60
nrdefault, 57	wa, 60
nrels, 57	wa_alloc, 60
ntime, 57	_braid_GridDestroy
phi, 57	_braid.h, 65
print_level, 57	_braid_GridElt
pstatus, 57	_braid.h, 63
refine, 57	_braid_GridInit
rfactors, 58	_braid.h, 65
rnorm, 58	_braid_InitGuess
rtol, 58	_braid.h, 65
spatialnorm, 58	_braid_InitHierarchy
sum, 58	_braid.h, 65
tnorm, 58	_braid_IsCPoint
tnorm_a, 58	_braid.h, 63
tol, 58	_braid_IsFPoint
tstart, 58	braid.h, 63
tstop, 58	_braid_MapCoarseToFine
_braid_CoreElt	braid.h, 63
braid.h, 63	_braid_MapFineToCoarse
_braid_CoreFcn	braid.h, 63
_braid.h, 63	_braid_Max
braid FAccess	util.h, 71
braid.h, 64	_braid_ParFprintfFlush
-	·
_braid_FCRelax	util.h, 71
_braid.h, 64	_braid_Phi
_braid_FInterp	_braid.h, 65
_braid.h, 64	_braid_PhiStatus, 61
_braid_FRefine	accuracy, 61
_braid.h, 64	rfactor, 61
_braid_FRestrict	tstart, 61
_braid.h, 64	tstop, 61
_braid_GetDistribution	_braid_PhiStatusDestroy
_braid.h, 64	XBraid status routines, 41
_braid_GetProc	_braid_PhiStatusInit
_braid.h, 64	XBraid status routines, 41
_braid_Grid, 58	_braid_ProjectInterval
cfactor, 59	util.h, 71
clower, 59	_braid_Refine
cupper, 59	_braid.h, 65
gupper, 59	_braid_SetAccuracy
ilower, 59	util.h, 71
iupper, 59	_braid_StatusElt
level, 59	XBraid status routines, 39
10,00	אטומוט זומוט זיטנווופי, טי

_braid_Step	braid_AccessStatusGetResidual
_braid.h, 65	XBraid status routines, 42
_braid_TAlloc	braid_AccessStatusGetT
braid_defs.h, 68	XBraid status routines, 42
_braid_TFree	braid_AccessStatusGetTILD
braid_defs.h, 68	XBraid status routines, 42
_braid_TReAlloc	braid_AccessStatusGetWrapperTest
braid_defs.h, 68	XBraid status routines, 42
braid UAccessVector	braid_App
braid.h, 65	User-written routines, 26
braid UCommInit	braid CoarsenRefStatus
braid.h, 65	XBraid status routines, 39
_braid_UCommInitF	braid_CoarsenRefStatusGetCTprior
_braid.h, 65	XBraid status routines, 42
braid UCommWait	braid_CoarsenRefStatusGetCTstop
braid.h, 66	XBraid status routines, 43
braid UGetInterval	braid CoarsenRefStatusGetFTprior
	-
_braid.h, 66	XBraid status routines, 43
_braid_UGetVector	braid_CoarsenRefStatusGetFTstop
_braid.h, 66	XBraid status routines, 43
_braid_UGetVectorRef	braid_CoarsenRefStatusGetTpriorTstop
_braid.h, 66	XBraid status routines, 43
_braid_USetVector	braid_CoarsenRefStatusGetTstart
_braid.h, 66	XBraid status routines, 43
_braid_USetVectorRef	braid_Core
_braid.h, 66	General Interface routines, 30
_braid_error_flag	braid_Destroy
braid_defs.h, 69	General Interface routines, 31
_braid_printf	braid_Drive
util.h, 71	General Interface routines, 32
_braid_printfile	braid_GetNumIter
_braid.h, 66	General Interface routines, 32
	braid GetRNorm
access	General Interface routines, 32
_braid_Core, 55	braid Init
access_level	General Interface routines, 32
_braid_Core, 55	braid Int
accuracy	braid defs.h, 68
braid Core, 55	braid_PhiStatus
_braid_PhiStatus, 61	XBraid status routines, 39
app	braid_PhiStatusGetAccuracy
_braid_Core, 55	XBraid status routines, 44
	braid PhiStatusGetTstart
astatus	XBraid status routines, 44
_braid_Core, 55	braid PhiStatusGetTstartTstop
braid b CC	
braid.h, 66	XBraid status routines, 44
braid_AccessStatus	braid_PhiStatusGetTstop
XBraid status routines, 39	XBraid status routines, 44
braid_AccessStatusGetDone	braid_PhiStatusSetRFactor
XBraid status routines, 41	XBraid status routines, 44
braid_AccessStatusGetIter	braid_PrintStats
XBraid status routines, 41	General Interface routines, 33
braid_AccessStatusGetLevel	braid_PtFcnAccess
XBraid status routines, 41	User-written routines, 26

braid_PtFcnBufPack	braid_SetTemporalNorm
User-written routines, 26	General Interface routines, 36
braid_PtFcnBufSize	braid_SetTightxTol
User-written routines, 26	General Interface routines, 36
braid_PtFcnBufUnpack	braid_SplitCommworld
User-written routines, 27	General Interface routines, 36
braid_PtFcnClone	braid_TestAll
User-written routines, 27	XBraid test routines, 46
braid_PtFcnCoarsen	braid_TestBuf
User-written routines, 27	XBraid test routines, 47
braid_PtFcnFree	braid_TestClone
User-written routines, 27	XBraid test routines, 47
braid_PtFcnInit	braid_TestCoarsenRefine
User-written routines, 27	XBraid test routines, 48
braid_PtFcnPhi	braid_TestInitAccess
User-written routines, 27	XBraid test routines, 48
braid_PtFcnRefine	braid_TestSpatialNorm
User-written routines, 27	XBraid test routines, 49
braid_PtFcnSpatialNorm	braid_TestSum
User-written routines, 27	XBraid test routines, 49
braid_PtFcnSum	braid_Vector
User-written routines, 28	User-written routines, 28
braid_Real	braid_defs.h, 68
braid_defs.h, 68	_braid_CTAlloc, 68
braid_SetAbsTol	_braid_TAlloc, 68
General Interface routines, 33	_braid_TFree, 68
braid_SetAccessLevel	_braid_TReAlloc, 68
General Interface routines, 33	_braid_error_flag, 69
braid_SetCFactor	braid_Int, 68
General Interface routines, 33	braid_Real, 68
braid_SetFMG	braid_status.h, 69
General Interface routines, 34	braid_test.h, 70
braid_SetLoosexTol	buffer
General Interface routines, 34	_braid_CommHandle, 53
braid_SetMaxIter	bufpack
General Interface routines, 34	_braid_Core, 55
braid_SetMaxLevels	bufsize
General Interface routines, 34	_braid_Core, 56
braid_SetMinCoarse	bufunpack
General Interface routines, 34	_braid_Core, 56
braid_SetNFMGVcyc	
General Interface routines, 34	c_tprior
braid_SetNRelax	_braid_CoarsenRefStatus, 53
General Interface routines, 35	c_tstop
braid_SetPrintFile	_braid_CoarsenRefStatus, 53
General Interface routines, 35	cfactor
braid_SetPrintLevel	_braid_Grid, 59
General Interface routines, 35	cfactors
braid_SetRelTol	_braid_Core, 56
General Interface routines, 35	cfdefault
braid_SetSpatialCoarsen	_braid_Core, 56
General Interface routines, 35	clone
braid_SetSpatialRefine	_braid_Core, 56
General Interface routines, 36	clower

_braid_Grid, 59	_braid_Core, 56
coarsen	braid Grid, 59
_braid_Core, 56	/
comm	ilower
	_braid_Grid, 59
_braid_Core, 56	init
comm_world	·
_braid_Core, 56	_braid_Core, 56
cstatus	iter
_braid_Core, 56	_braid_AccessStatus, 51
cupper	iupper
_braid_Grid, 59	_braid_Grid, 59
	,
done	level
_braid_AccessStatus, 51	_braid_AccessStatus, 51
f_tprior	_braid_Grid, 59
—·	localtime
_braid_CoarsenRefStatus, 53	_braid_Core, 57
f_tstop	loose
_braid_CoarsenRefStatus, 53	_braid_AccuracyHandle, 52
fmg	,
_braid_Core, 56	matchF
free	braid AccuracyHandle, 52
_braid_Core, 56	
_braid_core, 30	max_iter
General Interface routines, 30	_braid_Core, 57
	max_levels
braid_Core, 30	_braid_Core, 57
braid_Destroy, 31	min coarse
braid_Drive, 32	braid Core, 57
braid_GetNumIter, 32	
braid_GetRNorm, 32	ncpoints
braid_Init, 32	•
braid PrintStats, 33	_braid_Grid, 59
	nfmg_Vcyc
braid_SetAbsTol, 33	_braid_Core, 57
braid_SetAccessLevel, 33	niter
braid_SetCFactor, 33	_braid_Core, 57
braid_SetFMG, 34	nlevels
braid_SetLoosexTol, 34	_braid_Core, 57
braid_SetMaxIter, 34	nrdefault
braid SetMaxLevels, 34	
braid SetMinCoarse, 34	_braid_Core, 57
	nrels
braid_SetNFMGVcyc, 34	_braid_Core, 57
braid_SetNRelax, 35	ntime
braid_SetPrintFile, 35	_braid_Core, 57
braid_SetPrintLevel, 35	num requests
braid_SetRelTol, 35	_braid_CommHandle, 54
braid_SetSpatialCoarsen, 35	_5/4/4_56///////////////////////////////
braid SetSpatialRefine, 36	old_value
braid_SetTemporalNorm, 36	
_ ·	_braid_AccuracyHandle, 52
braid_SetTightxTol, 36	-h:
braid_SplitCommworld, 36	phi
globaltime	_braid_Core, 57
_braid_Core, 56	print_level
grids	_braid_Core, 57
_braid_Core, 56	pstatus
gupper	_braid_Core, 57
9-FF-	

recv_handle	ua
_braid_Grid, 60	_braid_Grid, 60
recv_index	ua_alloc
_braid_Grid, 60	_braid_Grid, 60
refine	User interface routines, 29
_braid_Core, 57	User-written routines, 25
request_type	braid_App, 26
_braid_CommHandle, 54	braid_PtFcnAccess, 26
requests	braid_PtFcnBufPack, 26
braid CommHandle, 54	braid PtFcnBufSize, 26
rfactor	braid_PtFcnBufUnpack, 27
_braid_PhiStatus, 61	braid PtFcnClone, 27
rfactors	braid_PtFcnCoarsen, 27
_braid_Core, 58	braid_PtFcnFree, 27
rnorm	braid_PtFcnInit, 27
_braid_AccessStatus, 51	braid PtFcnPhi, 27
	braid PtFcnRefine, 27
_braid_Core, 58	braid_PtFcnSpatialNorm, 27
rtol	braid_PtFcnSum, 28
_braid_Core, 58	braid_Vector, 28
and broadle	util.h, 70
send_handle	
_braid_Grid, 60	_braid_Max, 71
send_index	_braid_ParFprintfFlush, 71
_braid_Grid, 60	_braid_ProjectInterval, 71
spatialnorm	_braid_SetAccuracy, 71
_braid_Core, 58	_braid_printf, 71
status	vo.
_braid_CommHandle, 54	va
sum	_braid_Grid, 60
_braid_Core, 58	va_alloc
	_braid_Grid, 60
t	value
_braid_AccessStatus, 51	_braid_AccuracyHandle, 52
ta	vector_ptr
_braid_Grid, 60	_braid_CommHandle, 54
ta_alloc	
braid Grid, 60	wa
tight	_braid_Grid, 60
braid AccuracyHandle, 52	wa_alloc
tight used	_braid_Grid, 60
_braid_AccuracyHandle, 52	wrapper_test
tnorm	_braid_AccessStatus, 51
	VDraid status routines 20
_braid_Core, 58	XBraid status routines, 38
tnorm_a	_braid_AccessStatusDestroy, 39
_braid_Core, 58	_braid_AccessStatusInit, 39
tol	_braid_CoarsenRefStatusDestroy, 39
_braid_Core, 58	_braid_CoarsenRefStatusInit, 39
tstart	_braid_PhiStatusDestroy, 41
_braid_CoarsenRefStatus, 53	_braid_PhiStatusInit, 41
_braid_Core, 58	_braid_StatusElt, 39
_braid_PhiStatus, 61	braid_AccessStatus, 39
tstop	braid_AccessStatusGetDone, 41
_braid_Core, 58	braid_AccessStatusGetIter, 41
_braid_PhiStatus, 61	braid_AccessStatusGetLevel, 41

```
braid_AccessStatusGetResidual, 42
    braid_AccessStatusGetT, 42
    braid_AccessStatusGetTILD, 42
    braid_AccessStatusGetWrapperTest, 42
    braid_CoarsenRefStatus, 39
    braid_CoarsenRefStatusGetCTprior, 42
    braid CoarsenRefStatusGetCTstop, 43
    braid_CoarsenRefStatusGetFTprior, 43
    braid_CoarsenRefStatusGetFTstop, 43
    braid_CoarsenRefStatusGetTpriorTstop, 43
    braid_CoarsenRefStatusGetTstart, 43
    braid PhiStatus, 39
    braid_PhiStatusGetAccuracy, 44
    braid PhiStatusGetTstart, 44
    braid_PhiStatusGetTstartTstop, 44
    braid_PhiStatusGetTstop, 44
    braid PhiStatusSetRFactor, 44
XBraid test routines, 46
    braid_TestAll, 46
    braid_TestBuf, 47
    braid_TestClone, 47
    braid_TestCoarsenRefine, 48
    braid_TestInitAccess, 48
    braid TestSpatialNorm, 49
    braid_TestSum, 49
```